




# PARTS CATALOGUE


## YZ250FW (5XCG) U.S.A.,CANADA
## YZ250F (5XCH) EUROPE
## YZ250F (5XCJ) JAPAN
## YZ250FW (5XCK) OCEANIA,SOUTH AFRICA

1F5XC-100E1

( 2F5XC-100E1 )



A2


A3

# FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
   It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations
   The following abbreviations are used in this Parts Catalogue.

   "UR" Use specified parts number.
   "UN" Use as many as needed.
   "AP" Alternate Parts
   "LM" Locally Made (Parts need to be ordered locally)
   "F#" Frame No. (Applicable machine No.)
   "O/S" Over Size

3. The number of components for assembly
   - Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
   - The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

| PART NO. | DESCRIPTION | Q'TY | REMARKS |
|---|---|---|---|
| 2F5–83310–60 | FRONT FLASHER LIGHT ASSY | 2 | |
| 115–83311–60 | .BULB (6V–18W) | 1 | |

4. Applicable colours of graphics are represented in the "REMARKS" as shown below.


| PART NO. | DESCRIPTION | Q'TY | REMARKS |
|---|---|---|---|
| 2N4–24110–00–X5 | FUEL TANK COMP. | 2 | MXR |
| 3J1–24240–10 | .GRAPHIC, FUEL TANK | 1 | FOR MXR |

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.


6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.




Frame Serial No.




8. Applicable Colour Code (The (*) mark shows Model colour.)

| Abbreviation | Colour Name | Colour Code |
|---|---|---|
| DPBSE(*) | DEEP PURPLISH BLUE SOLID E | 0583 |
| PWS1(*) | PURPLISH WHITE SOLID 1 | 0206 |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |


# MODEL LABEL

(1) A label called “Model Label” is affixed in the location as indicated in (3) below.
When using this parts catalogue, please be sure to cross–reference the “model code – production code No.” in the catalogue with the “model code – production code No.” indicated on the Model Label affixed onto the product concerned.


(2) “Model Label” Indication

a b
○ xxxx – xxx
● x c

a: Model Type Code
b: Production Code No.
c: Colouring Type




(3) Model Label Affixing Location




(4) Colouring Information

| Model Code | Colouring Type Code | Colour Code | Colour Name | Abbreviation |
|---|---|---|---|---|
| 5XCG | A | 0583 | DEEP PURPLISH BLUE SOLID E | DPBSE |
| | B | 0206 | PURPLISH WHITE SOLID 1 | PWS1 |
| 5XCH | A | 0583 | DEEP PURPLISH BLUE SOLID E | DPBSE |
| | B | 0206 | PURPLISH WHITE SOLID 1 | PWS1 |
| 5XCJ | A | 0583 | DEEP PURPLISH BLUE SOLID E | DPBSE |
| | B | 0206 | PURPLISH WHITE SOLID 1 | PWS1 |
| 5XCK | A | 0583 | DEEP PURPLISH BLUE SOLID E | DPBSE |
| | B | 0206 | PURPLISH WHITE SOLID 1 | PWS1 |
| | | | | |
| | | | | |

(5) Model Code – Production Code Number of Model Listed in This Parts Catalogue

| Model Code | Production Code No. | Country (destination) | Model Code | Production Code No. | Country (destination) |
|---|---|---|---|---|---|
| 5XCG | 010 | U.S.A. | | | |
| | 020 | CANADA | | | |
| 5XCH | 010 | EUROPE | | | |
| | 020 | FRANCE | | | |
| 5XCJ | 010 | JAPAN | | | |
| 5XCK | 010 | AUSTRALIA | | | |
| | | NEW ZEALAND | | | |
| | | SOUTH AFRICA | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

# CONTENTS

## ENGINE


CYLINDER ........ B2
CRANKSHAFT & PISTON ........ B4
VALVE ........ B5
CAMSHAFT & CHAIN ........ B7
WATER PUMP ........ B8
RADIATOR & HOSE ........ B9
OIL PUMP ........ B10
OIL CLEANER ........ B12
INTAKE ........ B13
CARBURETOR ........ B14
EXHAUST ........ C4
CRANKCASE ........ C5
CRANKCASE COVER 1 ........ C6
STARTER ........ C8
CLUTCH ........ C9
TRANSMISSION ........ C11
SHIFT CAM & FORK ........ C13
SHIFT SHAFT ........ C14

## CHASSIS

FRAME ........ C15
FENDER ........ D3
SIDE COVER & OIL TANK ........ D5
REAR ARM ........ D7
REAR SUSPENSION ........ D9
STEERING ........ D11
FRONT FORK ........ D12
FUEL TANK ........ D15
SEAT ........ E3
FRONT WHEEL ........ E4
FRONT BRAKE CALIPER ........ E5
REAR WHEEL ........ E6
REAR BRAKE CALIPER ........ E8
STEERING HANDLE & CABLE ........ E9
FRONT MASTER CYLINDER ........ E10
STAND & FOOTREST ........ E11
REAR MASTER CYLINDER ........ E12
GENERATOR ........ E13
HANDLE SWITCH & LEVER ........ E14
ELECTRICAL 1 ........ E15
ALTERNATE FOR CHASSIS ........ F2
ALTERNATE ........ F3


## INDEX

NUMERICAL INDEX ........ M1





## FIG. 1 CYLINDER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–11102–20 | CYLINDER HEAD ASSY | 1 | 1 | 1 | 1 | | |
| 2 | 5XC–11133–10 | .GUIDE, VALVE 1 | 3 | 3 | 3 | 3 | | |
| 3 | 5NL–11134–10 | .GUIDE, VALVE 2 | 2 | 2 | 2 | 2 | | |
| 4 | 93440–10153 | .CIRCLIP | 2 | 2 | 2 | 2 | | |
| 5 | 93440–07149 | .CIRCLIP | 3 | 3 | 3 | 3 | | |
| 6 | 91808–16023 | .PIN, DOWEL | 4 | 4 | 4 | 4 | | |
| 7 | 90105–06027 | .BOLT, FLANGE | 10 | 10 | 10 | 10 | | |
| 8 | 90340–12007 | .PLUG, STRAIGHT SCREW | 1 | 1 | 1 | 1 | | |
| 9 | 95022–06010 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 10 | 90430–06014 | GASKET | 1 | 1 | 1 | 1 | | |
| 11 | 90116–06038 | BOLT, STUD | 2 | 2 | 2 | 2 | | |
| 12 | 95612–08620 | BOLT, STUD | 2 | 2 | 2 | 2 | | |
| 13 | 95702–08500 | NUT, FLANGE | 2 | 2 | 2 | 2 | | |
| 14 | 94701–00411 | PLUG, SPARK (NGK R CR8E) | 1 | 1 | | 1 | | STD |
| | 94703–00411 | PLUG, SPARK (NGK R CR8E) | | | 1 | | | STD |
| | 94701–00410 | PLUG, SPARK (NGK R CR9E) | 1 | 1 | | 1 | | AP |
| | 94703–00410 | PLUG, SPARK (NGK R CR9E) | | | 1 | | | AP |
| 15 | 5NL–11181–00 | GASKET, CYLINDER HEAD 1 | 1 | 1 | 1 | 1 | | |
| 16 | 90105–09004 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 17 | 90105–09002 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 18 | 90201–096J9 | WASHER, PLATE | 4 | 4 | 4 | 4 | | |
| 19 | 5NL–11191–20 | COVER, CYLINDER HEAD 1 | 1 | 1 | 1 | 1 | | |
| 20 | 371–11167–01 | PIPE, BREATHER 2 | 1 | 1 | 1 | 1 | | |
| 21 | 5XC–11166–00 | PIPE, BREATHER 1 | 1 | 1 | 1 | 1 | | |
| 22 | 90467–140A4 | CLIP | 1 | 1 | 1 | 1 | | |
| 23 | 5UM–1119E–00 | BOLT, COVER HEAD | 2 | 2 | 2 | 2 | | |
| 24 | 5NL–11193–00 | GASKET, HEAD COVER 1 | 1 | 1 | 1 | 1 | | |




## FIG. 1 CYLINDER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 25 | 5XC–11311–10 | CYLINDER 1 | 1 | 1 | 1 | 1 | | |
| 26 | 5NL–11351–00 | GASKET, CYLINDER | 1 | 1 | 1 | 1 | | |
| 27 | 95702–06500 | NUT, FLANGE | 2 | 2 | 2 | 2 | | |
| 28 | 93612–16254 | PIN, DOWEL | 2 | 2 | 2 | 2 | | |
| 29 | 95022–06035 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |








5XCG100-F020


## FIG. 2 CRANKSHAFT & PISTON

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–11400–20 | CRANKSHAFT ASSY | 1 | 1 | 1 | 1 | | |
| 2 | 5UL–11412–20 | .CRANK 1 | 1 | 1 | 1 | 1 | | |
| 3 | 5UL–11422–10 | .CRANK 2 | 1 | 1 | 1 | 1 | | |
| 4 | 5XC–11681–00 | .PIN, CRANK 1 | 1 | 1 | 1 | 1 | | |
| 5 | 93310–63238 | .BEARING | 1 | 1 | 1 | 1 | | |
| 6 | 5XC–11651–00 | .ROD, CONNECTING | 1 | 1 | 1 | 1 | | |
| 7 | 93306–20648 | BEARING | 2 | 2 | 2 | 2 | | |
| 8 | 5NL–11536–00 | GEAR, DRIVE | 1 | 1 | 1 | 1 | | |
| 9 | 5NL–11455–00 | SHAFT 1 | 1 | 1 | 1 | 1 | | |
| 10 | 93306–20335 | BEARING | 1 | 1 | 1 | 1 | | |
| 11 | 90280–03006 | KEY, WOODRUFF | 1 | 1 | 1 | 1 | | |
| 12 | 5NL–11531–00 | GEAR, BALANCE WEIGHT | 1 | 1 | 1 | 1 | | |
| 13 | 5NL–11454–00 | WEIGHT 1 | 1 | 1 | 1 | 1 | | |
| 14 | 90149–06084 | SCREW | 2 | 2 | 2 | 2 | | |
| 15 | 90215–14204 | WASHER, LOCK | 1 | 1 | 1 | 1 | | |
| 16 | 90170–14171 | NUT | 1 | 1 | 1 | 1 | | |
| 17 | 93311–32261 | BEARING | 1 | 1 | 1 | 1 | | |
| 18 | 5NL–11631–20 | PISTON (STD) | 1 | 1 | 1 | 1 | | |
| 19 | 5NL–11603–00 | PISTON RING SET (STD) | 1 | 1 | 1 | 1 | | |
| 20 | 5NL–11633–00 | PIN, PISTON | 1 | 1 | 1 | 1 | | |
| 21 | 93420–16086 | CIRCLIP | 2 | 2 | 2 | 2 | | |




## FIG. 3 VALVE

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5NL–12111–20 | VALVE, INTAKE | 1 | 1 | 1 | 1 | | |
| 2 | 5NL–12112–20 | VALVE, INTAKE 2 | 2 | 2 | 2 | 2 | | |
| 3 | 5NL–12121–10 | VALVE, EXHAUST | 2 | 2 | 2 | 2 | | |
| 4 | 5NL–12116–00 | SEAT, VALVE SPRING | 3 | 3 | 3 | 3 | | |
| 5 | 3GM–12126–00 | SEAT, VALVE SPRING 2 | 2 | 2 | 2 | 2 | | |
| 6 | 4TV–12119–00 | SEAL, VALVE STEM | 3 | 3 | 3 | 3 | | |
| 7 | 4SV–12119–00 | SEAL, VALVE STEM | 2 | 2 | 2 | 2 | | |
| 8 | 5NL–12113–00 | SPRING, VALVE INNER | 3 | 3 | 3 | 3 | | |
| 9 | 5NL–12114–00 | SPRING, VALVE OUTER | 2 | 2 | 2 | 2 | | |
| 10 | 1HX–12117–00 | RETAINER, VALVE SPRING | 3 | 3 | 3 | 3 | | |
| 11 | 1HX–12118–00 | COTTER, VALVE | 6 | 6 | 6 | 6 | | |
| 12 | 1WG–12117–00 | RETAINER, VALVE SPRING | 2 | 2 | 2 | 2 | | |
| 13 | 1WG–12118–00 | COTTER, VALVE | 4 | 4 | 4 | 4 | | |
| 14 | 1HX–12168–00 | PAD, ADJUSTING 2 (1.20) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–20 | PAD, ADJUSTING 2 (1.25) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–40 | PAD, ADJUSTING 2 (1.30) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–60 | PAD, ADJUSTING 2 (1.35) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–80 | PAD, ADJUSTING 2 (1.40) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–A0 | PAD, ADJUSTING 2 (1.45) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–F0 | PAD, ADJUSTING 2 (1.50) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–H1 | PAD, ADJUSTING 2 (1.55) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–K1 | PAD, ADJUSTING 2 (1.60) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–M1 | PAD, ADJUSTING 2 (1.65) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–R1 | PAD, ADJUSTING 2 (1.70) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–U1 | PAD, ADJUSTING 2 (1.75) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–W1 | PAD, ADJUSTING 2 (1.80) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12168–Y1 | PAD, ADJUSTING 2 (1.85) | 5 | 5 | 5 | 5 | | UR |








5NL1100-1030

## FIG. 3 VALVE

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 14 | 1HX–12169–11 | PAD, ADJUSTING 2 (1.90) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12169–31 | PAD, ADJUSTING 2 (1.95) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12169–50 | PAD, ADJUSTING 2 (2.00) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12169–70 | PAD, ADJUSTING 2 (2.05) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12169–90 | PAD, ADJUSTING 2 (2.10) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12169–E0 | PAD, ADJUSTING 2 (2.15) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12169–G0 | PAD, ADJUSTING 2 (2.20) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12169–J0 | PAD, ADJUSTING 2 (2.25) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12169–L0 | PAD, ADJUSTING 2 (2.30) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12169–N0 | PAD, ADJUSTING 2 (2.35) | 5 | 5 | 5 | 5 | | UR |
| | 1HX–12169–T0 | PAD, ADJUSTING 2 (2.40) | 5 | 5 | 5 | 5 | | UR |
| 15 | 3LN–12153–10 | LIFTER, VALVE | 3 | 3 | 3 | 3 | | YELLOW |
| 16 | 3FV–12153–10 | LIFTER, VALVE | 2 | 2 | 2 | 2 | | YELLOW |








5XC9100-E040


## FIG. 4 CAMSHAFT & CHAIN

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5UL–12170–10 | CAMSHAFT ASSY 1 | 1 | 1 | 1 | 1 | | |
| 2 | 5UL–12180–10 | CAMSHAFT ASSY 2 | 1 | 1 | 1 | 1 | | |
| 3 | 93440–41178 | CIRCLIP | 2 | 2 | 2 | 2 | | |
| 4 | 94591–53114 | CHAIN | 1 | 1 | 1 | 1 | | |
| 5 | 5NL–12251–10 | DAMPER, CHAIN 1 | 1 | 1 | 1 | 1 | | |
| 6 | 5NL–12252–00 | DAMPER, CHAIN 2 | 1 | 1 | 1 | 1 | | |
| 7 | 97022–06016 | BOLT | 2 | 2 | 2 | 2 | | |
| 8 | 92902–06600 | WASHER, PLATE | 2 | 2 | 2 | 2 | | |
| 9 | 4FM–12213–00 | GASKET, TENSIONER CASE | 1 | 1 | 1 | 1 | | |
| 10 | 5TA–12210–20 | TENSIONER ASSY, CAM CHAIN | 1 | 1 | 1 | 1 | | |
| 11 | 95022–06025 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 12 | 5BE–12241–00 | GUIDE, STOPPER 2 | 1 | 1 | 1 | 1 | | |





## FIG. 5 WATER PUMP

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–12459–00 | GEAR, IMPELLER SHAFT | 1 | 1 | 1 | 1 | | |
| 2 | 90201–08512 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 3 | 93440–07182 | CIRCLIP | 1 | 1 | 1 | 1 | | |
| 4 | 5DH–12451–00 | IMPELLER, WATER PUMP | 1 | 1 | 1 | 1 | | |
| 5 | 90201–08512 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 6 | 93109–11073 | OIL SEAL | 1 | 1 | 1 | 1 | | |
| 7 | 93102–12106 | OIL SEAL (SD 12-22-5 HS) | 1 | 1 | 1 | 1 | | |
| 8 | 93306–00105 | BEARING | 1 | 1 | 1 | 1 | | |
| 9 | 5NL–12422–10 | COVER, HOUSING | 1 | 1 | 1 | 1 | | |
| 10 | 5NL–12439–00 | O-RING | 1 | 1 | 1 | 1 | | |
| 11 | 93604–10011 | PIN, DOWEL | 2 | 2 | 2 | 2 | | |
| 12 | 90430–06014 | GASKET | 1 | 1 | 1 | 1 | | |
| 13 | 95022–06025 | BOLT, FLANGE | 3 | 3 | 3 | 3 | | |
| 14 | 95022–06065 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 15 | 95022–06012 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |




## FIG. 6 RADIATOR & HOSE

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–1240A–G0 | RADIATOR ASSY | 1 | 1 | 1 | 1 | | |
| 2 | 2S2–12464–70 | .STAY, RADIATOR | 1 | 1 | 1 | 1 | | |
| 3 | 92012–06010 | .BOLT, BUTTON HEAD | 3 | 3 | 3 | 3 | | |
| 4 | 90183–060A6 | .NUT, SPRING | 1 | 1 | 1 | 1 | | |
| 5 | 5XC–12461–G0 | RADIATOR ASSY | 1 | 1 | 1 | 1 | | |
| 6 | 2S2–12464–70 | .STAY, RADIATOR | 1 | 1 | 1 | 1 | | |
| 7 | 92012–06010 | .BOLT, BUTTON HEAD | 3 | 3 | 3 | 3 | | |
| 8 | 90183–060A6 | .NUT, SPRING | 1 | 1 | 1 | 1 | | |
| 9 | 22W–12462–00 | CAP, RADIATOR | 1 | 1 | 1 | 1 | | |
| 10 | 91A20–05065 | TUBE, FLEXIBLE VINYL | 1 | 1 | 1 | 1 | | |
| 11 | 90467–090A2 | CLIP | 1 | 1 | 1 | 1 | | |
| 12 | 5XC–12481–G0 | PIPE 1 | 1 | 1 | 1 | 1 | | |
| 13 | 91312–06020 | BOLT | 1 | 1 | 1 | 1 | | |
| 14 | 93210–16275 | O-RING | 1 | 1 | 1 | 1 | | |
| 15 | 5XC–12576–G0 | HOSE 1 | 1 | 1 | 1 | 1 | | |
| 16 | 1C3–12482–00 | PIPE 2 | 1 | 1 | 1 | 1 | | |
| 17 | 5XC–12578–G0 | HOSE 3 | 1 | 1 | 1 | 1 | | |
| 18 | 5XC–12579–G0 | HOSE 4 | 1 | 1 | 1 | 1 | | |
| 19 | 90450–25001 | HOSE CLAMP ASSY | 2 | 2 | 2 | 2 | | |
| 20 | 90450–22001 | HOSE CLAMP ASSY | 4 | 4 | 4 | 4 | | |
| 21 | 90450–32003 | HOSE CLAMP ASSY | 2 | 2 | 2 | 2 | | |
| 22 | 90480–15528 | GROMMET | 4 | 4 | 4 | 4 | | |
| 23 | 90387–06065 | COLLAR | 4 | 4 | 4 | 4 | | |
| 24 | 90105–06111 | BOLT, FLANGE | 4 | 4 | 4 | 4 | | |
| 25 | 90201–06571 | WASHER, PLATE | 4 | 4 | 4 | 4 | | |








5XC9100-E070

## FIG. 7 OIL PUMP

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5SG–13300–00 | OIL PUMP ASSY | 1 | 1 | 1 | 1 | | |
| 2 | 93603–16219 | PIN, DOWEL | 1 | 1 | 1 | 1 | | |
| 3 | 5NL–13320–00 | ROTOR ASSY 2 | 1 | 1 | 1 | 1 | | |
| 4 | 93440–10153 | CIRCLIP | 1 | 1 | 1 | 1 | | |
| 5 | 99530–08012 | PIN, DOWEL | 1 | 1 | 1 | 1 | | |
| 6 | 91312–06025 | BOLT | 2 | 2 | 2 | 2 | | |
| 7 | 91317–06030 | BOLT | 1 | 1 | 1 | 1 | | |
| 8 | 93210–10197 | O-RING | 1 | 1 | 1 | 1 | | |
| 9 | 99530–10114 | PIN, DOWEL | 1 | 1 | 1 | 1 | | |
| 10 | 5BE–13342–00 | SHAFT, IDLE GEAR | 1 | 1 | 1 | 1 | | |
| 11 | 5NL–13341–00 | GEAR, OIL PUMP IDLE | 1 | 1 | 1 | 1 | | |
| 12 | 99001–08600 | CIRCLIP | 1 | 1 | 1 | 1 | | |
| 13 | 90201–12166 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 14 | 99009–12400 | CIRCLIP | 1 | 1 | 1 | 1 | | |
| 15 | 5XC–13412–00 | HOUSING, STRAINER | 1 | 1 | 1 | 1 | | |
| 16 | 5NL–13411–00 | STRAINER, OIL | 1 | 1 | 1 | 1 | | |
| 17 | 95022–06025 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 18 | 5XC–13464–30 | HOSE, OIL 1 | 1 | 1 | 1 | 1 | | |
| 19 | 93210–10197 | O-RING | 1 | 1 | 1 | 1 | | |
| 20 | 99530–10114 | PIN, DOWEL | 1 | 1 | 1 | 1 | | |
| 21 | 95022–06025 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 22 | 90450–22001 | HOSE CLAMP ASSY | 1 | 1 | 1 | 1 | | |
| 23 | 5XC–13465–30 | HOSE, OIL 2 | 1 | 1 | 1 | 1 | | |
| 24 | 95022–06025 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 25 | 93210–10197 | O-RING | 1 | 1 | 1 | 1 | | |
| 26 | 99530–10114 | PIN, DOWEL | 1 | 1 | 1 | 1 | | |
| 27 | 95022–06016 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |








5XC9100-E070

## FIG. 7 OIL PUMP

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | 93210–09754 | O-RING | 1 | 1 | 1 | 1 | | |
| 29 | 90445–14010 | HOSE | 1 | 1 | 1 | 1 | | |
| 30 | 90450–17001 | HOSE CLAMP ASSY | 2 | 2 | 2 | 2 | | |








5XCG100-F080


## FIG. 8 OIL CLEANER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5TA–13440–00 | ELEMENT ASSY, OIL CLEANER | 1 | 1 | 1 | 1 | | |
| 2 | 5BE–13447–10 | COVER, OIL ELEMENT | 1 | 1 | 1 | 1 | | |
| 3 | 93210–47675 | O-RING | 1 | 1 | 1 | 1 | | |
| 4 | 93210–07135 | O-RING | 3 | 3 | 3 | 3 | | |
| 5 | 90110–06228 | BOLT, HEXAGON SOCKET HEAD | 1 | 1 | 1 | 1 | | |
| 6 | 91312–06065 | BOLT | 1 | 1 | 1 | 1 | | |
| 7 | 91312–06025 | BOLT | 1 | 1 | 1 | 1 | | |
| 8 | 5NL–13161–20 | PIPE, DELIVERY 1 | 1 | 1 | 1 | 1 | | |
| 9 | 90401–10015 | BOLT, UNION | 1 | 1 | 1 | 1 | | |
| 10 | 90430–10188 | GASKET | 2 | 2 | 2 | 2 | | |
| 11 | 90401–08006 | BOLT, UNION | 2 | 2 | 2 | 2 | | |
| 12 | 90430–08119 | GASKET | 4 | 4 | 4 | 4 | | |
| 13 | 5NL–13171–00 | PIPE, DELIVERY 2 | 1 | 1 | 1 | 1 | | |
| 14 | 93210–07003 | O-RING | 1 | 1 | 1 | 1 | | |
| 15 | 93210–09008 | O-RING | 1 | 1 | 1 | 1 | | |
| 16 | 93210–12759 | O-RING | 1 | 1 | 1 | 1 | | |
| 17 | 95022–06012 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 18 | 90501–043E0 | SPRING, COMPRESSION | 1 | 1 | 1 | 1 | | |
| 19 | 93503–08007 | BALL | 1 | 1 | 1 | 1 | | |
| 20 | 583–13113–00 | SEAT, CHECK BALL | 1 | 1 | 1 | 1 | | |





## FIG. 9 INTAKE

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–13597–30 | JOINT, CARBURETOR 3 | 1 | 1 | 1 | 1 | | |
| 2 | 91312–06025 | BOLT | 2 | 2 | 2 | 2 | | |
| 3 | 90450–57010 | HOSE CLAMP ASSY | 1 | 1 | 1 | 1 | | |
| 4 | 5TA–14293–00 | COVER 1 | 1 | 1 | 1 | 1 | | |
| 5 | 5TA–14227–00 | GASKET | 1 | 1 | 1 | 1 | | |
| 6 | 5TA–14239–00 | SEAL | 1 | 1 | 1 | 1 | | |
| 7 | 5TA–14987–00 | HOSE | 1 | 1 | 1 | 1 | | |
| 8 | 3TJ–14137–40 | CLIP | 1 | 1 | 1 | 1 | | |
| 9 | 90110–05038 | BOLT, HEXAGON SOCKET HEAD | 2 | 2 | 2 | 2 | | |
| 10 | 90450–61002 | HOSE CLAMP ASSY | 1 | 1 | 1 | 1 | | |
| 11 | 2S2–14401–70 | AIR CLEANER CASE ASSY | 1 | 1 | 1 | 1 | | |
| 12 | 5XC–14453–G0 | JOINT, AIR CLEANER 1 | 1 | 1 | 1 | 1 | | |
| 13 | 5NY–14459–00 | HOLDER, GUIDE | 1 | 1 | 1 | 1 | | |
| 14 | 5NY–14455–20 | BAND | 1 | 1 | 1 | 1 | | |
| 15 | 5NY–14442–00 | SPACER | 1 | 1 | 1 | 1 | | |
| 16 | 5XC–14417–90 | COVER 1 | 1 | 1 | 1 | 1 | | |
| 17 | 90267–32070 | RIVET, BLIND | 3 | 3 | 3 | 3 | | |
| 18 | 90201–03313 | WASHER, PLATE | 6 | 6 | 6 | 6 | | |
| 19 | 4XM–14451–00 | ELEMENT, AIR CLEANER | 1 | 1 | 1 | 1 | | |
| 20 | 90209–06014 | WASHER | 1 | 1 | 1 | 1 | | |
| 21 | 90122–06005 | BOLT, WING | 1 | 1 | 1 | 1 | | |
| 22 | 5BE–14458–00 | GUIDE | 1 | 1 | 1 | 1 | | |
| 23 | 90109–067F4 | BOLT | 2 | 2 | 2 | 2 | | |





## FIG. 10 CARBURETOR

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–14101–G0 | CARBURETOR ASSY 1 | 1 | | | | | |
| | 5XC–14101–H0 | CARBURETOR ASSY 1 | | 1 | 1 | 1 | | |
| 2 | 5JG–14959–00 | .GASKET | 1 | 1 | 1 | 1 | | |
| 3 | 91316–04012 | .BOLT | 6 | 6 | 6 | 6 | | |
| 4 | 688–14592–00 | .SCREW | 3 | 3 | 3 | 3 | | |
| 5 | 90202–08045 | .WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 6 | 5JG–14951–00 | .WASHER | 1 | 1 | 1 | 1 | | |
| 7 | 5JG–14522–00 | .SCREW, ADJUST | 1 | 1 | 1 | 1 | | |
| 8 | 2S2–14388–00 | .VALVE, VACUUM CONTROL | 1 | 1 | 1 | 1 | | |
| 9 | 3TJ–14267–40 | .ROLLER | 1 | 1 | 1 | 1 | | |
| 10 | 5JG–14546–01 | .VALVE, NEEDLE | 1 | 1 | 1 | 1 | | |
| 11 | 4FN–14997–00 | .SEAL | 1 | 1 | 1 | 1 | | |
| 12 | 5NL–14916–P1 | .NEEDLE (#OBEPQ) | 1 | 1 | 1 | 1 | | STD |
| | 5NL–14916–PM | .NEEDLE (#OBEPM) | 1 | 1 | 1 | 1 | | AP |
| | 5NL–14916–PN | .NEEDLE (#OBEPN) | 1 | 1 | 1 | 1 | | AP |
| | 5NL–14916–PP | .NEEDLE (#OBEPP) | 1 | 1 | 1 | 1 | | AP |
| | 5NL–14916–PR | .NEEDLE (#OBEPR) | 1 | 1 | 1 | 1 | | AP |
| | 5NL–14916–PS | .NEEDLE (#OBEPS) | 1 | 1 | 1 | 1 | | AP |
| | 5NL–14916–PT | .NEEDLE (#OBEPT) | 1 | 1 | 1 | 1 | | AP |
| 13 | 3TJ–14159–40 | .CLIP | 1 | 1 | 1 | 1 | | |
| 14 | 5JG–14521–00 | .SCREW, ADJUST | 1 | 1 | 1 | 1 | | |
| 15 | 5JG–14275–00 | .SPRING | 1 | 1 | 1 | 1 | | |
| 16 | 5JG–14264–00 | .COLLAR | 1 | 1 | 1 | 1 | | |
| 17 | 5XC–14947–00 | .JET, NEEDLE | 1 | 1 | 1 | 1 | | |
| 18 | 4MX–14943–93 | .JET, MAIN (#178) | 1 | 1 | 1 | 1 | | STD |
| | 4MX–14943–91 | .JET, MAIN (#168) | 1 | 1 | 1 | 1 | | AP |
| | 4MX–14943–41 | .JET, MAIN (#170) | 1 | 1 | 1 | 1 | | AP |





## FIG. 10 CARBURETOR

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 18 | 4MX–14943–92 | .JET, MAIN (#172) | 1 | 1 | 1 | 1 | | AP |
| | 4MX–14943–42 | .JET, MAIN (#175) | 1 | 1 | 1 | 1 | | AP |
| | 4MX–14943–43 | .JET, MAIN (#180) | 1 | 1 | 1 | 1 | | AP |
| | 4MX–14943–94 | .JET, MAIN (#182) | 1 | 1 | 1 | 1 | | AP |
| | 4MX–14943–44 | .JET, MAIN (#185) | 1 | 1 | 1 | 1 | | AP |
| | 4MX–14943–95 | .JET, MAIN (#188) | 1 | 1 | 1 | 1 | | AP |
| 19 | 4MX–14948–04 | .JET, SLOW (#42) | 1 | 1 | 1 | 1 | | STD |
| | 4MX–14948–02 | .JET, SLOW (#38) | 1 | 1 | 1 | 1 | | AP |
| | 4MX–14948–03 | .JET, SLOW (#40) | 1 | 1 | 1 | 1 | | AP |
| | 4MX–14948–05 | .JET, SLOW (#45) | 1 | 1 | 1 | 1 | | AP |
| | 4MX–14948–06 | .JET, SLOW (#48) | 1 | 1 | 1 | 1 | | AP |
| 20 | 3TJ–1494F–16 | .JET (#72) | 1 | 1 | 1 | 1 | | STD |
| | 3TJ–1494F–13 | .JET (#65) | 1 | 1 | 1 | 1 | | AP |
| | 3TJ–1494F–14 | .JET (#68) | 1 | 1 | 1 | 1 | | AP |
| | 3TJ–1494F–15 | .JET (#70) | 1 | 1 | 1 | 1 | | AP |
| | 3TJ–1494F–17 | .JET (#75) | 1 | 1 | 1 | 1 | | AP |
| | 3TJ–1494F–18 | .JET (#78) | 1 | 1 | 1 | 1 | | AP |
| | 3TJ–1494F–19 | .JET (#80) | 1 | 1 | 1 | 1 | | AP |
| 21 | 4JT–1494F–19 | .JET (#80) | 1 | | | | | STD |
| | 4JT–1494F–15 | .JET (#70) | | 1 | 1 | 1 | | STD |
| | 4JT–1494F–03 | .JET (#40) | | 1 | 1 | 1 | | AP |
| | 4JT–1494F–07 | .JET (#50) | 1 | 1 | 1 | 1 | | AP |
| | 4JT–1494F–11 | .JET (#60) | 1 | 1 | 1 | 1 | | AP |
| | 4JT–1494F–15 | .JET (#70) | 1 | | | | | AP |
| | 4JT–1494F–19 | .JET (#80) | | 1 | 1 | 1 | | AP |
| | 4JT–1494F–23 | .JET (#90) | 1 | 1 | 1 | 1 | | AP |
| | 4JT–1494F–27 | .JET(#100) | 1 | 1 | 1 | 1 | | AP |





## FIG. 10 CARBURETOR

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | REMARKS |
|---|---|---|---|---|---|---|---|
| 21 | 4JT–1494F–29 | .JET(#110) | 1 | | | | AP |
| 22 | 5TA–14943–28 | .JET, MAIN (#105) | 1 | 1 | 1 | 1 | |
| 23 | 5NL–14105–00 | .PILOT SCREW SET | 1 | 1 | 1 | 1 | |
| 24 | 4SR–14985–00 | .FLOAT | 1 | 1 | 1 | 1 | |
| 25 | 676–14548–00 | .PIN, FLOAT ARM | 1 | 1 | 1 | 1 | |
| 26 | 4MX–14392–00 | .VALVE, NEEDLE | 1 | 1 | 1 | 1 | |
| 27 | 633–14159–00 | .CLIP | 1 | 1 | 1 | 1 | |
| 28 | 5JG–14984–00 | .GASKET, FLOAT CHAMBER | 1 | 1 | 1 | 1 | |
| 29 | 3TJ–14191–40 | .PLUG, DRAIN | 1 | 1 | 1 | 1 | |
| 30 | 3TJ–14293–40 | .COVER 1 | 1 | 1 | 1 | 1 | |
| 31 | 5JG–14940–76 | .DIAPHRAGM ASSY | 1 | 1 | 1 | 1 | STD |
| | 5JG–14940–16 | .DIAPHRAGM ASSY | 1 | 1 | 1 | 1 | AP |
| | 5JG–14940–17 | .DIAPHRAGM ASSY | 1 | 1 | 1 | 1 | AP |
| | 5JG–14940–18 | .DIAPHRAGM ASSY | 1 | 1 | 1 | 1 | AP |
| 32 | 3TJ–14536–40 | .GASKET | 1 | 1 | 1 | 1 | |
| 33 | 3TJ–14933–40 | .SPRING, DIAPHRAGM | 1 | 1 | 1 | 1 | |
| 34 | 6H4–14561–00 | .O-RING | 1 | 1 | 1 | 1 | |
| 35 | 5XC–14171–00 | .PLUNGER, STARTER | 1 | 1 | 1 | 1 | |
| 36 | 5TA–14371–00 | .PLUNGER, STARTER | 1 | 1 | 1 | 1 | |
| 37 | 5TA–14335–00 | .SPRING, PLUNGER | 1 | 1 | 1 | 1 | |
| 38 | 5TA–14991–00 | .SCREW | 1 | 1 | 1 | 1 | |
| 39 | 2S2–14374–00 | .CAP, PLUNGER | 1 | 1 | 1 | 1 | |
| 40 | 5TA–14155–00 | .GUIDE, CABLE | 1 | 1 | 1 | 1 | |
| 41 | 5TA–14997–00 | .SEAL | 1 | 1 | 1 | 1 | |
| 42 | 5JG–14379–00 | .ROD, STARTER | 1 | 1 | 1 | 1 | |
| 43 | 3TJ–14564–40 | .O-RING | 3 | 3 | 3 | 3 | |
| 44 | 5XC–14922–00 | .SCREW, THROTTLE | 1 | 1 | 1 | 1 | |





## FIG. 10 CARBURETOR

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 45 | 90201–08410 | .WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 46 | 5TA–14934–00 | .SPRING, THROTTLE STOP | 1 | 1 | 1 | 1 | | |
| 47 | 5XC–85885–00 | .THROTTLE SENSOR ASSY | 1 | 1 | 1 | 1 | | |
| 48 | 5NX–14562–00 | .O-RING | 1 | 1 | 1 | 1 | | |
| 49 | 5NX–14216–00 | .SCREW | 1 | 1 | 1 | 1 | | |
| 50 | 4MX–14561–00 | .O-RING | 1 | 1 | 1 | 1 | | |
| 51 | 4MX–14115–00 | .PLUG, SCREW | 1 | 1 | 1 | 1 | | |
| 52 | 3TJ–14137–40 | .CLIP | 5 | 5 | 5 | 5 | | |
| 53 | 5BE–14146–00 | .PLATE | 2 | 2 | 2 | 2 | | |
| 54 | 5TA–14261–00 | .HOLDER | 1 | 1 | 1 | 1 | | |
| 55 | 5UL–14196–00 | .PIPE | 2 | 2 | 2 | 2 | | |
| 56 | 5TA–14197–00 | .PIPE | 2 | 2 | 2 | 2 | | |
| 57 | 5TJ–14987–00 | .HOSE | 1 | 1 | 1 | 1 | | |
| 58 | 5JG–14346–00 | .PLATE | 1 | 1 | 1 | 1 | | |
| 59 | 5JG–14565–00 | .SCREW | 1 | 1 | 1 | 1 | | |
| 60 | 5JG–14531–00 | .SPRING, ADJUST SCREW | 1 | 1 | 1 | 1 | | |
| 61 | 5NL–14591–00 | .SCREW | 1 | 1 | 1 | 1 | | |
| 62 | 5PA–14146–00 | .PLATE | 1 | 1 | 1 | 1 | | |
| 63 | 5XD–14325–00 | .SCREW, PAN HEAD | 1 | 1 | 1 | 1 | | |





## FIG. 11 EXHAUST

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–14611–20 | PIPE, EXHAUST 1 | 1 | 1 | 1 | 1 | | |
| 2 | 5XC–14628–00 | PROTECTOR, EXHAUST PIPE | 1 | 1 | 1 | 1 | | |
| 3 | 4BD–14766–00 | WASHER, PROTECTOR | 6 | 6 | 6 | 6 | | |
| 4 | 98980–06008 | SCREW, BIND | 3 | 3 | 3 | 3 | | |
| 5 | 90206–06090 | WASHER, WAVE | 3 | 3 | 3 | 3 | | |
| 6 | 5NL–14613–00 | GASKET, EXHAUST PIPE | 1 | 1 | 1 | 1 | | |
| 7 | 5XC–14750–30 | SILENCER ASSY | 1 | | | | | |
| | 5XC–14750–40 | SILENCER ASSY | | 1 | 1 | 1 | | |
| 8 | 90267–48084 | .RIVET, BLIND | 16 | 16 | 16 | 16 | | |
| 9 | 5XC–1469A–00 | .FIBER | 1 | | | | | |
| | 5XC–1469A–10 | .FIBER | | 1 | 1 | 1 | | |
| 10 | 2S2–1469E–00 | .FIBER | 1 | 1 | 1 | 1 | | |
| 11 | 2S2–1469F–00 | .FIBER | 1 | 1 | 1 | 1 | | |
| 12 | 5XD–14714–00 | .GASKET, MUFFLER | 1 | 1 | 1 | 1 | | |
| 13 | 5BE–14747–00 | .DAMPER, MUFFLER | 1 | 1 | 1 | 1 | | |
| 14 | 90387–08081 | .COLLAR | 1 | 1 | 1 | 1 | | |
| 15 | 5BE–14788–00 | BAND, SILENCER | 1 | 1 | 1 | 1 | | |
| 16 | 90201–08061 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 17 | 90105–08137 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 18 | 90105–08307 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |





## FIG. 12 CRANKCASE

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–15150–20–YX | CRANKCASE ASSY | 1 | 1 | 1 | 1 | | |
| 2 | 93612–16254 | PIN, DOWEL | 2 | 2 | 2 | 2 | | |
| 3 | 91312–06045 | BOLT | 6 | 6 | 6 | 6 | | |
| 4 | 91312–06055 | BOLT | 1 | 1 | 1 | 1 | | |
| 5 | 91312–06070 | BOLT | 4 | 4 | 4 | 4 | | |
| 6 | 95022–10016 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 7 | 90430–10188 | GASKET | 1 | 1 | 1 | 1 | | |
| 8 | 5NL–15441–01 | HOLDER, CLUTCH CABLE | 1 | 1 | 1 | 1 | | |
| 9 | 5BE–15421–10 | COVER, CRANKCASE 2 | 1 | 1 | 1 | 1 | | |
| 10 | 98502–06025 | SCREW, PAN HEAD | 2 | 2 | 2 | 2 | | |
| 11 | 5NL–17466–00 | GUIDE, CHAIN | 1 | 1 | 1 | 1 | | |
| 12 | 5BE–15383–01 | PLATE, BEARING COVER | 4 | 4 | 4 | 4 | | |
| 13 | 90149–06085 | SCREW | 4 | 4 | 4 | 4 | | |
| 14 | 5NL–15388–00 | PLATE, BEARING COVER | 1 | 1 | 1 | 1 | | |
| 15 | 90105–06081 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 16 | 4JT–15381–01 | PLATE, BEARING COVER | 4 | 4 | 4 | 4 | | |
| 17 | 90149–06074 | SCREW | 4 | 4 | 4 | 4 | | |
| 18 | 5DH–18562–00 | PLATE, STOPPER 2 | 5 | 5 | 5 | 5 | | |
| 19 | 90105–06081 | BOLT, FLANGE | 5 | 5 | 5 | 5 | | |
| 20 | 93210–10197 | O-RING | 1 | 1 | 1 | 1 | | |
| 21 | 99530–10114 | PIN, DOWEL | 1 | 1 | 1 | 1 | | |
| 22 | 90387–18007 | COLLAR | 2 | 2 | 2 | 2 | | |
| 23 | 99530–10116 | PIN, DOWEL | 2 | 2 | 2 | 2 | | |
| 24 | 90465–10013 | CLAMP | 1 | 1 | 1 | 1 | | |





## FIG. 13 CRANKCASE COVER 1

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5NL–15411–20 | COVER, CRANKCASE 1 | 1 | 1 | 1 | 1 | | |
| 2 | 90340–32123 | PLUG, STRAIGHT SCREW | 1 | 1 | 1 | 1 | | |
| 3 | 93210–32172 | O-RING | 1 | 1 | 1 | 1 | | |
| 4 | 90340–14128 | PLUG, STRAIGHT SCREW | 1 | 1 | 1 | 1 | | |
| 5 | 93210–14369 | O-RING | 1 | 1 | 1 | 1 | | |
| 6 | 3Y1–15363–00 | PLUG, OIL | 1 | 1 | 1 | 1 | | |
| 7 | 93210–19123 | O-RING | 1 | 1 | 1 | 1 | | |
| 8 | 5NL–15451–00 | GASKET, CRANKCASE COVER 1 | 1 | 1 | 1 | 1 | | |
| 9 | 99530–08016 | PIN, DOWEL | 2 | 2 | 2 | 2 | | |
| 10 | 95022–06035 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 11 | 95022–06025 | BOLT, FLANGE | 6 | 6 | 6 | 6 | | |
| 12 | 5XC–15431–01 | COVER, CRANKCASE 3 | 1 | 1 | 1 | 1 | | |
| 13 | 93101–14164 | OIL SEAL | 1 | 1 | 1 | 1 | | |
| 14 | 90201–15701 | WASHER, PLATE (T=1.0) | 1 | 1 | 1 | 1 | | |
| 15 | 99009–22500 | CIRCLIP | 1 | 1 | 1 | 1 | | |
| 16 | 5XC–15373–00 | PIPE, BREATHER | 1 | 1 | 1 | 1 | | |
| 17 | 5NL–15462–00 | GASKET, CRANKCASE COVER 3 | 1 | 1 | 1 | 1 | | |
| 18 | 91812–16001 | PIN, DOWEL | 2 | 2 | 2 | 2 | | |
| 19 | 95022–06035 | BOLT, FLANGE | 8 | 8 | 8 | 8 | | |
| 20 | 5NL–12564–00 | PIPE, WATER | 2 | 2 | 2 | 2 | | |
| 21 | 93210–16716 | O-RING | 2 | 2 | 2 | 2 | | |
| 22 | 5NL–15415–10 | COVER, GENERATOR | 1 | 1 | 1 | 1 | | |
| 23 | 95022–06025 | BOLT, FLANGE | 4 | 4 | 4 | 4 | | |
| 24 | 95022–06035 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 25 | 90105–06098 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 26 | 99530–08016 | PIN, DOWEL | 2 | 2 | 2 | 2 | | |
| 27 | 5NL–15453–10 | GASKET | 1 | 1 | 1 | 1 | | |





## FIG. 13 CRANKCASE COVER 1

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | 90465–08029 | CLAMP | 1 | 1 | 1 | 1 | | |
| 29 | 2S2–15378–00 | HOLDER | 1 | 1 | 1 | 1 | | |
| 30 | 3Y1–15361–00 | GAUGE, LEVEL | 1 | 1 | 1 | 1 | | |
| 31 | 5XC–15118–00 | HOLDER | 1 | 1 | 1 | 1 | | |
| 32 | 90105–06094 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |





## FIG. 14 STARTER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5NL–15601–20 | KICK SHAFT ASSY | 1 | 1 | 1 | 1 | | |
| 2 | 5NL–15641–20 | .GEAR, KICK | 1 | 1 | 1 | 1 | | |
| 3 | 90201–20685 | .WASHER, PLATE (T=0.5) | 1 | 1 | 1 | 1 | | |
| 4 | 93410–20038 | .CIRCLIP | 1 | 1 | 1 | 1 | | |
| 5 | 2S2–15671–00 | .WHEEL, RATCHET | 1 | 1 | 1 | 1 | | |
| 6 | 90501–160A2 | .SPRING, COMPRESSION | 1 | 1 | 1 | 1 | | |
| 7 | 90201–167P7 | .WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 8 | 99009–16400 | .CIRCLIP | 1 | 1 | 1 | 1 | | |
| 9 | 90508–30743 | .SPRING, TORSION | 1 | 1 | 1 | 1 | | |
| 10 | 5NL–15664–00 | .GUIDE, SPRING | 1 | 1 | 1 | 1 | | |
| 11 | 90201–162H4 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 12 | 5SG–15668–00 | STOPPER | 1 | 1 | 1 | 1 | | |
| 13 | 214–15686–00 | WASHER, LOCK | 1 | 1 | 1 | 1 | | |
| 14 | 90101–06044 | BOLT | 2 | 2 | 2 | 2 | | |
| 15 | 93102–18278 | OIL SEAL | 1 | 1 | 1 | 1 | | |
| 16 | 5NL–15651–00 | GEAR, KICK IDLE | 1 | 1 | 1 | 1 | | |
| 17 | 90201–177G4 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 18 | 99009–17400 | CIRCLIP | 1 | 1 | 1 | 1 | | |
| 19 | 5XC–15620–10 | KICK CRANK ASSY | 1 | 1 | 1 | 1 | | |
| 20 | 5XC–15621–10 | .BOSS, KICK CRANK | 1 | 1 | 1 | 1 | | |
| 21 | 90501–147A5 | .SPRING, COMPRESSION | 1 | 1 | 1 | 1 | | |
| 22 | 93507–32009 | .BALL | 1 | 1 | 1 | 1 | | |
| 23 | 90152–06010 | .SCREW, COUNTERSUNK | 1 | 1 | 1 | 1 | | |
| 24 | 93210–17570 | .O-RING | 1 | 1 | 1 | 1 | | |
| 25 | 90201–08048 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 26 | 90110–08051 | BOLT, HEXAGON SOCKET HEAD | 1 | 1 | 1 | 1 | | |





## FIG. 15 CLUTCH

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5NL–16111–00 | GEAR, PRIMARY DRIVE | 1 | 1 | 1 | 1 | | |
| 2 | 90215–20003 | WASHER, LOCK | 1 | 1 | 1 | 1 | | |
| 3 | 90179–18001 | NUT | 1 | 1 | 1 | 1 | | |
| 4 | 5NL–16150–10 | PRIMARY DRIVEN GEAR COMP. | 1 | 1 | 1 | 1 | | |
| 5 | 5NL–16154–00 | PLATE, THRUST 1 | 1 | 1 | 1 | 1 | | |
| 6 | 5NL–16371–00 | BOSS, CLUTCH | 1 | 1 | 1 | 1 | | |
| 7 | 5DH–16321–00 | PLATE, FRICTION | 7 | 7 | 7 | 7 | | |
| 8 | 5NL–16325–00 | PLATE, CLUTCH 2 | 7 | 7 | 7 | 7 | | |
| 9 | 5HD–16351–00 | PLATE, PRESSURE 1 | 1 | 1 | 1 | 1 | | |
| 10 | 90501–224J9 | SPRING, COMPRESSION | 5 | 5 | 5 | 5 | | (PINK) |
| 11 | 90159–06092 | SCREW, WITH WASHER | 5 | 5 | 5 | 5 | | |
| 12 | 3XJ–16321–00 | PLATE, FRICTION | 2 | 2 | 2 | 2 | | |
| 13 | 5NL–16384–00 | PLATE, SEAT | 1 | 1 | 1 | 1 | | |
| 14 | 5NL–16383–10 | SPRING, CLUTCH BOSS | 1 | 1 | 1 | 1 | | |
| 15 | 5NL–16325–10 | PLATE, CLUTCH 2 | 1 | 1 | 1 | 1 | | |
| 16 | 90215–16289 | WASHER, LOCK | 1 | 1 | 1 | 1 | | |
| 17 | 90170–16326 | NUT | 1 | 1 | 1 | 1 | | |
| 18 | 5NL–16356–00 | ROD, PUSH 1 | 1 | 1 | 1 | 1 | | |
| 19 | 93340–21008 | BEARING | 1 | 1 | 1 | 1 | | |
| 20 | 90201–080H1 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 21 | 93440–07182 | CIRCLIP | 1 | 1 | 1 | 1 | | |
| 22 | 93511–32027 | BALL | 1 | 1 | 1 | 1 | | |
| 23 | 5NL–16357–10 | ROD, PUSH 2 | 1 | 1 | 1 | 1 | | |
| 24 | 5JG–16381–10 | PUSH LEVER COMP. | 1 | 1 | 1 | 1 | | |
| 25 | 93317–11287 | BEARING | 1 | 1 | 1 | 1 | | |
| 26 | 93102–12224 | OIL SEAL | 1 | 1 | 1 | 1 | | |
| 27 | 4JT–16384–00 | PLATE, SEAT | 1 | 1 | 1 | 1 | | |





## FIG. 15 CLUTCH

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | 95022–06010 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |





## FIG. 16 TRANSMISSION

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5NL–17411–10 | AXLE,MAIN (14T) | 1 | 1 | 1 | 1 | | |
| 2 | 93306–20447 | BEARING | 1 | 1 | 1 | 1 | | |
| 3 | 5NL–17151–00 | GEAR, 5TH PINION (24T) | 1 | 1 | 1 | 1 | | |
| 4 | 90209–20008 | WASHER | 2 | 2 | 2 | 2 | | |
| 5 | 93410–22039 | CIRCLIP | 3 | 3 | 3 | 3 | | |
| 6 | 5NL–17131–10 | GEAR, 3RD PINION (20T) | 1 | 1 | 1 | 1 | | |
| 7 | 5NL–17141–11 | GEAR, 4TH PINION (22T) | 1 | 1 | 1 | 1 | | |
| 8 | 90387–20006 | COLLAR | 1 | 1 | 1 | 1 | | |
| 9 | 5NL–17121–00 | GEAR, 2ND PINION (16T) | 1 | 1 | 1 | 1 | | |
| 10 | 93306–00320 | BEARING | 1 | 1 | 1 | 1 | | |
| 11 | 93306–27208 | BEARING | 1 | 1 | 1 | 1 | | |
| 12 | 5NL–17402–00 | DRIVE AXLE ASSY | 1 | 1 | 1 | 1 | | |
| 13 | 5NL–17221–00 | GEAR, 2ND WHEEL (28T) | 1 | 1 | 1 | 1 | | |
| 14 | 90209–23012 | WASHER | 1 | 1 | 1 | 1 | | |
| 15 | 93410–26067 | CIRCLIP | 1 | 1 | 1 | 1 | | |
| 16 | 5NL–17241–11 | GEAR, 4TH WHEEL (27T) | 1 | 1 | 1 | 1 | | |
| 17 | 5NL–17231–11 | GEAR, 3RD WHEEL (29T) | 1 | 1 | 1 | 1 | | |
| 18 | 90209–20008 | WASHER | 1 | 1 | 1 | 1 | | |
| 19 | 93410–22039 | CIRCLIP | 1 | 1 | 1 | 1 | | |
| 20 | 5NL–17251–10 | GEAR, 5TH WHEEL (25T) | 1 | 1 | 1 | 1 | | |
| 21 | 5NL–17211–10 | GEAR, 1ST WHEEL (30T) | 1 | 1 | 1 | 1 | | |
| 22 | 93306–00317 | BEARING | 1 | 1 | 1 | 1 | | |
| 23 | 93210–196A4 | O-RING | 1 | 1 | 1 | 1 | | |
| 24 | 90387–22001 | COLLAR | 1 | 1 | 1 | 1 | | |
| 25 | 93102–28010 | OIL SEAL | 1 | 1 | 1 | 1 | | |
| 26 | 9383B–13218 | SPROCKET, DRIVE (13T) | 1 | 1 | 1 | 1 | | |
| 27 | 90215–20003 | WASHER, LOCK | 1 | 1 | 1 | 1 | | |




## FIG. 16 TRANSMISSION

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | 90179–18001 | NUT | 1 | 1 | 1 | 1 | | |
| 29 | 5NL–17471–10 | PLATE, COVER | 1 | 1 | 1 | 1 | | |
| 30 | 90105–06081 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |








5XC9100-E170

## FIG. 17 SHIFT CAM & FORK

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5NL–18541–00 | CAM, SHIFT | 1 | 1 | 1 | 1 | | |
| 2 | 93306–90509 | BEARING | 1 | 1 | 1 | 1 | | |
| 3 | 90501–06022 | SPRING, COMPRESSION | 1 | 1 | 1 | 1 | | |
| 4 | 4UN–18542–00 | POINT, NEUTRAL | 1 | 1 | 1 | 1 | | |
| 5 | 5NL–18501–00 | FORK, SHIFT 1 | 1 | 1 | 1 | 1 | | |
| 6 | 5NL–18502–00 | FORK, SHIFT 2 | 1 | 1 | 1 | 1 | | |
| 7 | 5NL–18503–00 | FORK, SHIFT 3 | 1 | 1 | 1 | 1 | | |
| 8 | 3XK–18140–00 | STOPPER LEVER ASSY | 1 | 1 | 1 | 1 | | |
| 9 | 90508–26561 | SPRING, TORSION | 1 | 1 | 1 | 1 | | |
| 10 | 90109–06193 | BOLT | 1 | 1 | 1 | 1 | | |








5XCG100-F180


## FIG. 18 SHIFT SHAFT

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 2S2–18185–00 | SEGMENT | 1 | 1 | 1 | 1 | | |
| 2 | 3XJ–18173–10 | PIN, SHIFT | 1 | 1 | 1 | 1 | | |
| 3 | 5BE–18172–00 | GUIDE, SHIFT | 1 | 1 | 1 | 1 | | |
| 4 | 90101–06041 | BOLT | 2 | 2 | 2 | 2 | | |
| 5 | 5LP–18122–01 | LEVER, SHIFT 2 | 1 | 1 | 1 | 1 | | |
| 6 | 90501–052G5 | SPRING, COMPRESSION | 2 | 2 | 2 | 2 | | |
| 7 | 3XJ–18184–00 | PIN, PAWL | 2 | 2 | 2 | 2 | | |
| 8 | 3XJ–18182–00 | PAWL, SHIFTER | 2 | 2 | 2 | 2 | | |
| 9 | 3XJ–18178–00 | ROLLER, SHIFT LEVER | 1 | 1 | 1 | 1 | | |
| 10 | 5UL–18101–10 | SHIFT SHAFT ASSY | 1 | 1 | 1 | 1 | | |
| 11 | 90387–124F4 | COLLAR | 1 | 1 | 1 | 1 | | |
| 12 | 90508–291A8 | SPRING, TORSION | 1 | 1 | 1 | 1 | | |
| 13 | 93608–33002 | PIN, DOWEL | 1 | 1 | 1 | 1 | | |
| 14 | 93102–12224 | OIL SEAL | 1 | 1 | 1 | 1 | | |
| 15 | 5XC–18110–00 | SHIFT PEDAL ASSY | 1 | 1 | 1 | 1 | | |
| 16 | 95022–06020 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |





## FIG. 19 FRAME

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–21101–G0 | FRONT FRAME COMP. | 1 | 1 | 1 | 1 | | |
| 2 | 1C3–21447–10 | .BRACKET, FOOTREST | 1 | 1 | 1 | 1 | | |
| 3 | 1C3–21448–10 | .BRACKET, FOOTREST | 1 | 1 | 1 | 1 | | |
| 4 | 90149–10031 | .SCREW | 4 | 4 | 4 | 4 | | |
| 5 | 2S2–21190–70 | REAR FRAME COMP. | 1 | 1 | 1 | 1 | | |
| 6 | 90105–08156 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 7 | 90105–08307 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 8 | 30X–22178–00 | TENSIONER | 1 | 1 | 1 | 1 | | |
| 9 | 4V4–22184–00 | BUSH | 1 | 1 | 1 | 1 | | |
| 10 | 90201–08045 | WASHER, PLATE | 2 | 2 | 2 | 2 | | |
| 11 | 90387–08041 | COLLAR | 1 | 1 | 1 | 1 | | |
| 12 | 95022–08040 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 13 | 3JD–22178–20 | TENSIONER | 1 | 1 | 1 | 1 | | |
| 14 | 93300–60839 | BEARING | 1 | 1 | 1 | 1 | | |
| 15 | 90387–086N4 | COLLAR | 1 | 1 | 1 | 1 | | |
| 16 | 90105–08146 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 17 | 90185–08009 | NUT, SELF-LOCKING | 1 | 1 | 1 | 1 | | |
| 18 | 90201–08043 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 19 | 90105–10174 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 20 | 90179–10658 | NUT | 1 | 1 | 1 | 1 | | |
| 21 | 90201–10045 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 22 | 90105–08150 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 23 | 5XC–21425–G0 | BRACKET, REAR UPPER 1 | 1 | 1 | 1 | 1 | | |
| 24 | 5XC–21426–G0 | BRACKET, REAR UPPER 2 | 1 | 1 | 1 | 1 | | |
| 25 | 90105–10191 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 26 | 90105–08147 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 27 | 90201–10045 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |





## FIG. 19 FRAME

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | REMARKS |
|---|---|---|---|---|---|---|---|
| 28 | 92902–08200 | WASHER | 4 | 4 | 4 | 4 | |
| 29 | 90105–10176 | BOLT, FLANGE | 1 | 1 | 1 | 1 | |
| 30 | 90179–10658 | NUT | 1 | 1 | 1 | 1 | |
| 31 | 90201–10045 | WASHER, PLATE | 1 | 1 | 1 | 1 | |
| 32 | 1C3–21244–10 | NUT | 1 | 1 | 1 | 1 | |
| 33 | 5XC–21417–G0 | BRACKET, FRONT LOWER 1 | 1 | 1 | 1 | 1 | |
| 34 | 5XC–21418–G0 | BRACKET, FRONT LOWER 2 | 1 | 1 | 1 | 1 | |
| 35 | 90105–08143 | BOLT, FLANGE | 4 | 4 | 4 | 4 | |
| 36 | 92902–08200 | WASHER | 4 | 4 | 4 | 4 | |
| 37 | 5XC–21456–90 | PLATE, PATCH | 2 | 2 | 2 | 2 | |
| 38 | 5XC–21471–90 | PROTECTOR, ENGINE | 1 | 1 | 1 | 1 | |
| 39 | 90119–06146 | BOLT, WITH WASHER | 1 | 1 | 1 | 1 | |
| 40 | 5XC–2147E–G0 | GUARD, ENGINE 2 | 1 | 1 | 1 | 1 | |
| 41 | 90119–06146 | BOLT, WITH WASHER | 3 | 3 | 3 | 3 | |
| 42 | 5XC–21486–90 | DAMPER 2 | 1 | 1 | 1 | 1 | |
| 43 | 5XC–21274–90 | BRACKET, C.D.I. UNIT | 1 | 1 | 1 | 1 | |
| 44 | 90151–06032 | SCREW, COUNTERSUNK | 2 | 2 | 2 | 2 | |
| 45 | 5XC–21163–90 | HOLDER, CLUTCH CABLE | 1 | 1 | 1 | 1 | |
| 46 | 5XC–21164–90 | HOLDER, CABLE | 1 | 1 | 1 | 1 | |
| 47 | 92012–05008 | BOLT, BUTTON HEAD | 2 | 2 | 2 | 2 | |
| 48 | 5XC–21288–90 | GUIDE, CABLE | 1 | 1 | 1 | 1 | |
| 49 | 90105–05014 | BOLT, FLANGE | 1 | 1 | 1 | 1 | |
| 50 | 5ET–28166–10 | WRENCH, HEXAGON | 1 | 1 | 1 | 1 | |
| 51 | 5TA–2814F–00 | BOX, SPARK PLUG | 1 | 1 | 1 | 1 | |
| 52 | 5XC–28116–00 | TOOL, SPECIAL | 1 | 1 | 1 | 1 | |





## FIG. 20 FENDER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 1C3–21511–51 | FENDER, FRONT | 1 | 1 | 1 | 1 | | UR FOR DPBSE |
| | 2S2–21511–70 | FENDER, FRONT | 1 | 1 | 1 | 1 | | UR FOR PWS1 |
| 2 | 90387–06090 | COLLAR | 4 | 4 | 4 | 4 | | |
| 3 | 90119–06147 | BOLT, WITH WASHER | 4 | 4 | 4 | 4 | | |
| 4 | 4ES–2153E–01 | EMBLEM, YAMAHA | 1 | 1 | 1 | 1 | | UR FOR DPBSE |
| | 4ES–2153E–20 | EMBLEM, YAMAHA | 1 | 1 | 1 | 1 | | UR FOR PWS1 |
| 5 | 3FB–2415E–01 | LABEL, CAUTION | 1 | | | | | |
| | 3FB–2415E–C0 | LABEL, CAUTION | | | 1 | | | JAPANESE |
| 6 | 3FB–2415E–11 | LABEL, CAUTION | 1 | | | | | FOR CAN |
| 7 | 4SR–2416E–00 | LABEL, CAUTION CANADA | 1 | | | | | FOR CAN |
| 8 | 5XC–21610–90 | REAR FENDER COMP. | 1 | 1 | 1 | 1 | | UR FOR DPBSE |
| | 2S2–21610–70 | REAR FENDER COMP. | 1 | 1 | 1 | 1 | | UR FOR PWS1 |
| 9 | 5XE–21635–10 | .NUT, REAR FENDER | 2 | 2 | 2 | 2 | | |
| 10 | 90105–06100 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 11 | 90201–06032 | WASHER, PLATE | 2 | 2 | 2 | 2 | | |
| 12 | 90105–06106 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 13 | 90201–06571 | WASHER, PLATE | 2 | 2 | 2 | 2 | | |
| 14 | 90387–06009 | COLLAR | 2 | 2 | 2 | 2 | | |
| 15 | 5TA–21642–00 | GUARD, FLAP | 1 | 1 | 1 | 1 | | |
| 16 | 97702–60016 | SCREW, TAPPING | 2 | 2 | 2 | 2 | | |
| 17 | 5XC–2153E–00 | EMBLEM, YAMAHA | 1 | 1 | 1 | 1 | | UR FOR DPBSE |
| | 5XC–2153E–10 | EMBLEM, YAMAHA | 1 | 1 | 1 | 1 | | UR FOR PWS1 |
| 18 | 5PA–2118K–00 | LABEL, CAUTION | 1 | | | | | |
| | 5PA–2118K–20 | LABEL, CAUTION | | | 1 | | | JAPANESE |
| 19 | 5PA–2118K–10 | LABEL, CAUTION | 1 | | | | | FOR CAN |
| 20 | 3XJ–2151H–A1 | LABEL 5 | 1 | | | | | |
| | 4LB–2151H–02 | LABEL 5 | | | 1 | | | JAPANESE |





## FIG. 20 FENDER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 21 | 3XJ–2151H–B1 | LABEL 5 | 1 | | | | | FOR CAN |
| 22 | 5PA–21568–00 | LABEL, WARNING | | 1 | | 1 | | |
| 23 | 5XC–2163G–10 | EMBLEM 1 | 2 | 2 | 2 | 2 | | UR FOR DPBSE |
| | 2S2–2165A–00 | GRAPHIC SET,REAR FENDER | 1 | 1 | 1 | 1 | | UR FOR PWS1 |
| 24 | 3ME–2415E–01 | LABEL, CAUTION | | 1 | | | | |





## FIG. 21 SIDE COVER & OIL TANK

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–21710–90 | SIDE COVER ASSY 1 | 1 | 1 | 1 | 1 | | |
| 2 | 90105–06103 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 3 | 90119–08095 | BOLT, WITH WASHER | 1 | 1 | 1 | 1 | | |
| 4 | 5XC–21720–90 | SIDE COVER ASSY 2 | 1 | 1 | 1 | 1 | | |
| 5 | 90105–06103 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 6 | 90119–08095 | BOLT, WITH WASHER | 1 | 1 | 1 | 1 | | |
| 7 | 5XC–21730–90 | SIDE COVER ASSY 3 | 1 | 1 | 1 | 1 | | UR FOR DPBSE |
| | 2S2–21730–70 | SIDE COVER ASSY 3 | 1 | 1 | 1 | 1 | | UR FOR PWS1 |
| 8 | 5XC–2173E–10 | GRAPHIC 1 | 1 | 1 | 1 | 1 | | UR FOR DPBSE |
| | 5XC–2173L–10 | GRAPHIC SET 1 | 1 | 1 | 1 | 1 | | UR FOR PWS1 |
| 9 | 90105–06064 | BOLT, FLANGE | 4 | 4 | 4 | 4 | | |
| 10 | 2S2–2172A–70 | PANEL 1 | 1 | 1 | 1 | 1 | | |
| 11 | 5XC–21740–90 | SIDE COVER ASSY 4 | 1 | 1 | 1 | 1 | | UR FOR DPBSE |
| | 2S2–21740–70 | SIDE COVER ASSY 4 | 1 | 1 | 1 | 1 | | UR FOR PWS1 |
| 12 | 5XC–2173F–10 | GRAPHIC 2 | 1 | 1 | 1 | 1 | | UR FOR DPBSE |
| | 5XC–2174L–10 | GRAPHIC SET 2 | 1 | 1 | 1 | 1 | | UR FOR PWS1 |
| 13 | 90105–06064 | BOLT, FLANGE | 4 | 4 | 4 | 4 | | |
| 14 | 2S2–2172A–80 | PANEL 1 | 1 | 1 | 1 | 1 | | |
| 15 | 5XC–21751–G0 | TANK, OIL | 1 | 1 | 1 | 1 | | |
| 16 | 5XC–13416–90 | PIPE, OIL 1 | 1 | 1 | 1 | 1 | | |
| 17 | 93210–14369 | O-RING | 1 | 1 | 1 | 1 | | |
| 18 | 91312–06016 | BOLT | 1 | 1 | 1 | 1 | | |
| 19 | 90105–08151 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 20 | 90201–082A6 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 21 | 90105–06128 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 22 | 90201–06630 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 23 | 90480–10289 | GROMMET | 2 | 2 | 2 | 2 | | |





## FIG. 21 SIDE COVER & OIL TANK

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 24 | 90387–06150 | COLLAR | 2 | 2 | 2 | 2 | | |
| 25 | 90201–06571 | WASHER, PLATE | 3 | 3 | 3 | 3 | | |
| 26 | 90105–06112 | BOLT, FLANGE | 3 | 3 | 3 | 3 | | |
| 27 | 90480–14433 | GROMMET | 1 | 1 | 1 | 1 | | |
| 28 | 90387–06161 | COLLAR | 1 | 1 | 1 | 1 | | |





## FIG. 22 REAR ARM

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 2S2–22110–70 | REAR ARM COMP. | 1 | 1 | 1 | 1 | | |
| 2 | 90151–04003 | SCREW, COUNTERSUNK | 4 | 4 | 4 | 4 | | |
| 3 | 1C3–22355–00 | PATCH | 2 | 2 | 2 | 2 | | |
| 4 | 93317–22262 | BEARING | 4 | 4 | 4 | 4 | | |
| 5 | 93342–22217 | BEARING | 2 | 2 | 2 | 2 | | |
| 6 | 93106–22002 | OIL SEAL | 2 | 2 | 2 | 2 | | |
| 7 | 93109–28043 | OIL SEAL | 2 | 2 | 2 | 2 | | |
| 8 | 90387–18012 | COLLAR | 2 | 2 | 2 | 2 | | |
| 9 | 90387–18004 | COLLAR | 2 | 2 | 2 | 2 | | |
| 10 | 2S2–22151–70 | SEAL, GUARD | 1 | 1 | 1 | 1 | | |
| 11 | 1C3–22969–90 | SCREW, 1 | 4 | 4 | 4 | 4 | | |
| 12 | 2S2–22199–70 | SUPPORT, CHAIN | 1 | 1 | 1 | 1 | | |
| 13 | 2S2–22128–70 | COVER, THRUST 1 | 1 | 1 | 1 | 1 | | |
| 14 | 90105–06104 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 15 | 90179–06028 | NUT | 2 | 2 | 2 | 2 | | |
| 16 | 90105–06105 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 17 | 1C3–22141–10 | SHAFT, PIVOT | 1 | 1 | 1 | 1 | | |
| 18 | 90185–16002 | NUT, SELF-LOCKING | 1 | 1 | 1 | 1 | | |
| 19 | 90201–16018 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 20 | 5XC–2217A–G0 | ARM, RELAY | 1 | 1 | 1 | 1 | | |
| 21 | 93315–32166 | BEARING | 4 | 4 | 4 | 4 | | |
| 22 | 93109–25001 | OIL SEAL | 4 | 4 | 4 | 4 | | |
| 23 | 90387–16010 | COLLAR | 2 | 2 | 2 | 2 | | |
| 24 | 90209–16011 | WASHER | 4 | 4 | 4 | 4 | | |
| 25 | 90201–21014 | WASHER, PLATE | 4 | 4 | 4 | 4 | | |
| 26 | 5XC–2217F–G0 | ROD, CONNECTING 1 | 1 | 1 | 1 | 1 | | |
| 27 | 93315–32166 | BEARING | 2 | 2 | 2 | 2 | | |





## FIG. 22 REAR ARM

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | 93109–21001 | OIL SEAL | 2 | 2 | 2 | 2 | | |
| 29 | 90387–14005 | COLLAR | 1 | 1 | 1 | 1 | | |
| 30 | 5XC–22121–91 | SHAFT 1 | 1 | 1 | 1 | 1 | | |
| 31 | 1C3–22122–00 | SHAFT 2 | 2 | 2 | 2 | 2 | | |
| 32 | 90201–14020 | WASHER, PLATE | 3 | 3 | 3 | 3 | | |
| 33 | 90185–14010 | NUT, SELF-LOCKING | 3 | 3 | 3 | 3 | | |
| 34 | 1C3–2135F–00 | COVER | 1 | 1 | 1 | 1 | | |
| 35 | 1C3–2139R–00 | COVER 2 | 1 | 1 | 1 | 1 | | |
| 36 | 3RV–21668–A0 | LABEL, TIRE | 1 | 1 | | 1 | | |
| 37 | 3RV–21668–B0 | LABEL, TIRE | 1 | | | | | FOR CAN |





## FIG. 23 REAR SUSPENSION

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | REMARKS |
|---|---|---|---|---|---|---|---|
| 1 | 5XC–22200–G0 | SHOCK ABSORBER ASSY, REAR | 1 | | | | UR FOR USA |
| | 5XC–22200–L0 | SHOCK ABSORBER ASSY, REAR | 1 | | | | UR FOR CAN |
| | 5XC–22200–H0 | SHOCK ABSORBER ASSY, REAR | | 1 | | | |
| | 5XC–22200–J0 | SHOCK ABSORBER ASSY, REAR | | | 1 | | |
| | 5XC–22200–K0 | SHOCK ABSORBER ASSY, REAR | | | | 1 | |
| 2 | 5XC–22201–G0 | .DAMPER SUB ASSY | 1 | | 1 | 1 | |
| | 5XC–22201–H0 | .DAMPER SUB ASSY | | 1 | | | |
| 3 | 3SP–22234–00 | ..GUIDE, SPRING 3 | 1 | 1 | 1 | 1 | |
| 4 | 1C3–22213–L0 | ..SEAT, SPRING UPPER | 1 | 1 | 1 | 1 | |
| 5 | 509–23184–L0 | ..CAP, AIR VALVE | 1 | 1 | 1 | 1 | |
| 6 | 4JX–22226–00 | ..BUSH, SHOCK ABSORBER LOWER | 1 | 1 | 1 | 1 | |
| 7 | 5DH–23183–00 | ..CIRCLIP | 1 | 1 | 1 | 1 | |
| 8 | 4AA–22259–80 | ..LABEL, WARNING | 1 | | | | UR FOR USA |
| | 4AA–22259–60 | ..LABEL, WARNING | 1 | | | | UR FOR CAN |
| | 4AA–22259–40 | ..LABEL, WARNING | | 1 | | 1 | |
| | 4AA–22259–50 | ..LABEL, WARNING | | | 1 | | |
| 9 | 5MV–22224–00 | .GUIDE, SPRING 2 | 1 | 1 | 1 | 1 | |
| 10 | 1C3–22253–50 | .COLLAR, DISTANCE | 2 | 2 | 2 | 2 | |
| 11 | 3JE–22475–00 | .SEAL, DUST | 2 | 2 | 2 | 2 | |
| 12 | 4EW–22474–00 | .SEAL, RING | 2 | 2 | 2 | 2 | |
| 13 | 5UN–22176–00 | .BEARING | 1 | 1 | 1 | 1 | |
| 14 | 5MV–22184–00 | .BUSH | 1 | 1 | 1 | 1 | |
| 15 | 1C3–22253–L0 | .COLLAR, DISTANCE | 2 | 2 | 2 | 2 | |
| 16 | 5NY–22475–00 | .SEAL, DUST | 2 | 2 | 2 | 2 | |
| 17 | 1C3–22212–20 | .SPRING (K=48N/MM) | 1 | 1 | 1 | 1 | |
| 18 | 1C3–22214–50 | .GUIDE, SPRING 1 | 1 | 1 | 1 | 1 | |
| 19 | 1C3–22565–00 | .SPRING SEAT | 2 | 2 | 2 | 2 | |





## FIG. 23 REAR SUSPENSION

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 20 | 5XE–22242–00 | BOLT 2 | 1 | 1 | 1 | 1 | | |
| 21 | 95602–10200 | NUT, U FLANGE | 1 | 1 | 1 | 1 | | |
| 22 | 92902–10200 | WASHER | 1 | 1 | 1 | 1 | | |
| 23 | 5NY–22241–00 | BOLT 1 | 1 | 1 | 1 | 1 | | |
| 24 | 90185–10012 | NUT, SELF-LOCKING | 1 | 1 | 1 | 1 | | |




## FIG. 24 STEERING

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 93332–00068 | BEARING | 1 | 1 | 1 | 1 | | |
| 2 | 4EW–23416–00 | COVER, BALL RACE 2 | 1 | 1 | 1 | 1 | | |
| 3 | 90179–28003 | NUT | 1 | 1 | 1 | 1 | | |
| 4 | 90201–286K9 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 5 | 2S2–23435–70 | CROWN, HANDLE | 1 | 1 | 1 | 1 | | |
| 6 | 90170–24003 | NUT | 1 | 1 | 1 | 1 | | |
| 7 | 90201–24016 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 8 | 5XC–23441–90 | HOLDER, HANDLE UPPER | 2 | 2 | 2 | 2 | | |
| 9 | 2S2–23442–70 | HOLDER, HANDLE LOWER | 2 | 2 | 2 | 2 | | |
| 10 | 92902–10200 | WASHER | 2 | 2 | 2 | 2 | | |
| 11 | 95602–10200 | NUT, U FLANGE | 2 | 2 | 2 | 2 | | |
| 12 | 90105–08154 | BOLT, FLANGE | 8 | 8 | 8 | 8 | | |
| 13 | 1C3–23485–80 | PLATE, NUMBER | 1 | 1 | 1 | 1 | | |
| 14 | 90119–06151 | BOLT, WITH WASHER | 1 | 1 | 1 | 1 | | |
| 15 | 5XE–23389–00 | GUIDE, CABLE | 1 | 1 | 1 | 1 | | |
| 16 | 90105–06107 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 17 | 90387–06104 | COLLAR | 1 | 1 | 1 | 1 | | |








5XCG100-F250

## FIG. 25 FRONT FORK

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–23102–G0 | FRONT FORK ASSY (L.H) | 1 | | 1 | 1 | | |
| | 5XC–23102–H0 | FRONT FORK ASSY (L.H) | | 1 | | | | |
| 2 | 1C3–23136–N0 | .TUBE, OUTER (RIGHT) | 1 | 1 | 1 | 1 | | |
| 3 | 5XC–23120–M0 | .INNER TUBE COMP.2 | 1 | 1 | 1 | 1 | | |
| 4 | 5XE–23171–L0 | .PISTON, FRONT FORK | 1 | 1 | 1 | 1 | | |
| 5 | 5XE–23125–L0 | .METAL, SLIDE 1 | 1 | 1 | 1 | 1 | | |
| 6 | 5XE–23146–L0 | .WASHER, OIL SEAL | 1 | 1 | 1 | 1 | | |
| 7 | 1C3–23145–M0 | .OIL SEAL | 1 | 1 | 1 | 1 | | |
| 8 | 5XE–23153–L0 | .RING, SNAP | 1 | 1 | 1 | 1 | | |
| 9 | 5XE–23144–L0 | .SEAL, DUST | 1 | 1 | 1 | 1 | | |
| 10 | 5XC–23170–M0 | .CYLINDER COMP., FRONT FORK | 1 | | 1 | 1 | | |
| | 5XC–23170–N0 | .CYLINDER COMP., FRONT FORK | | 1 | | | | |
| 11 | 1C3–23147–L0 | ..O-RING | 1 | 1 | 1 | 1 | | |
| 12 | 5XC–2316A–R0 | .VALVE COMP. | 1 | | 1 | 1 | | |
| | 5XC–2316A–S0 | .VALVE COMP. | | 1 | | | | |
| 13 | 1C3–23188–L0 | ..O-RING | 1 | 1 | 1 | 1 | | |
| 14 | 1C3–23188–N0 | ..O-RING | 1 | 1 | 1 | 1 | | |
| 15 | 1C3–23188–P0 | ..O-RING | 1 | 1 | 1 | 1 | | |
| 16 | 1C3–23188–R0 | ..O-RING | 1 | 1 | 1 | 1 | | |
| 17 | 1AE–23147–00 | ..O-RING | 2 | 2 | 2 | 2 | | |
| 18 | 1C3–23190–L0 | .AIR VALVE COMP. | 1 | 1 | 1 | 1 | | |
| 19 | 1C3–23142–L0 | .SEAT, SPRING UPPER | 1 | 1 | 1 | 1 | | |
| 20 | 1P8–23141–M1 | .SPRING, FRONT FORK(K=4.2N/MM) | 1 | 1 | 1 | 1 | | |
| 21 | 1C3–23111–L1 | .BOLT, CAP | 1 | 1 | 1 | 1 | | |
| 22 | 2HH–23158–L0 | ..GASKET | 1 | 1 | 1 | 1 | | |
| 23 | 276–23114–00 | ..GASKET | 1 | 1 | 1 | 1 | | |
| 24 | 1C3–2314F–M0 | .PROTECTER GUIDE COMP., 1 | 1 | 1 | 1 | 1 | | |








5XCG100-F250

## FIG. 25 FRONT FORK

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | REMARKS |
|---|---|---|---|---|---|---|---|
| 25 | 5XC–23103–G0 | FRONT FORK ASSY (R.H) | 1 | | 1 | 1 | |
| | 5XC–23103–H0 | FRONT FORK ASSY (R.H) | | 1 | | | |
| 26 | 1C3–23136–N0 | .TUBE, OUTER (RIGHT) | 1 | 1 | 1 | 1 | |
| 27 | 5XC–23110–M0 | .INNER TUBE COMP.1 | 1 | 1 | 1 | 1 | |
| 28 | 5XE–23171–L0 | .PISTON, FRONT FORK | 1 | 1 | 1 | 1 | |
| 29 | 5XE–23125–L0 | .METAL, SLIDE 1 | 1 | 1 | 1 | 1 | |
| 30 | 5XE–23146–L0 | .WASHER, OIL SEAL | 1 | 1 | 1 | 1 | |
| 31 | 1C3–23145–M0 | .OIL SEAL | 1 | 1 | 1 | 1 | |
| 32 | 5XE–23153–L0 | .RING, SNAP | 1 | 1 | 1 | 1 | |
| 33 | 5XE–23144–L0 | .SEAL, DUST | 1 | 1 | 1 | 1 | |
| 34 | 5XC–23170–M0 | .CYLINDER COMP., FRONT FORK | 1 | | 1 | 1 | |
| | 5XC–23170–N0 | .CYLINDER COMP., FRONT FORK | | 1 | | | |
| 35 | 1C3–23147–L0 | ..O-RING | 1 | 1 | 1 | 1 | |
| 36 | 5XC–2316A–R0 | .VALVE COMP. | 1 | | 1 | 1 | |
| | 5XC–2316A–S0 | .VALVE COMP. | | 1 | | | |
| 37 | 1C3–23188–L0 | ..O-RING | 1 | 1 | 1 | 1 | |
| 38 | 1C3–23188–N0 | ..O-RING | 1 | 1 | 1 | 1 | |
| 39 | 1C3–23188–P0 | ..O-RING | 1 | 1 | 1 | 1 | |
| 40 | 1C3–23188–R0 | ..O-RING | 1 | 1 | 1 | 1 | |
| 41 | 1AE–23147–00 | ..O-RING | 2 | 2 | 2 | 2 | |
| 42 | 1C3–23190–L0 | .AIR VALVE COMP. | 1 | 1 | 1 | 1 | |
| 43 | 1C3–23142–L0 | .SEAT, SPRING UPPER | 1 | 1 | 1 | 1 | |
| 44 | 1P8–23141–M1 | .SPRING, FRONT FORK(K=4.2N/MM) | 1 | 1 | 1 | 1 | |
| 45 | 1C3–23111–L1 | .BOLT, CAP | 1 | 1 | 1 | 1 | |
| 46 | 2HH–23158–L0 | ..GASKET | 1 | 1 | 1 | 1 | |
| 47 | 276–23114–00 | ..GASKET | 1 | 1 | 1 | 1 | |
| 48 | 1C3–2314F–M0 | .PROTECTER GUIDE COMP., 1 | 1 | 1 | 1 | 1 | |








5XCG100-F250


## FIG. 25 FRONT FORK

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 49 | 5XC–23340–N0 | UNDER BRACKET COMP. | 1 | 1 | 1 | 1 | | |
| 50 | 93332–00081 | BEARING | 1 | 1 | 1 | 1 | | |
| 51 | 90105–08154 | BOLT, FLANGE | 8 | 8 | 8 | 8 | | |
| 52 | 1C3–2315H–10 | PROTECTOR 1 | 1 | 1 | 1 | 1 | | |
| 53 | 4XL–2153A–10 | EMBLEM, YAMAHA | 1 | 1 | 1 | 1 | | |
| 54 | 1C3–2315J–10 | PROTECTOR 2 | 1 | 1 | 1 | 1 | | |
| 55 | 4XL–2153A–10 | EMBLEM, YAMAHA | 1 | 1 | 1 | 1 | | |
| 56 | 3SP–23356–L0 | BOLT 2 | 6 | 6 | 6 | 6 | | |
| 57 | 1C3–23466–50 | CLAMP | 1 | 1 | 1 | 1 | | |
| 58 | 1C3–23467–50 | CLAMP | 1 | 1 | 1 | 1 | | |
| 59 | 95702–06500 | NUT, FLANGE | 2 | 2 | 2 | 2 | | |





## FIG. 26 FUEL TANK

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 2S2–24110–70 | FUEL TANK COMP. | 1 | 1 | 1 | 1 | | |
| 2 | 5NY–24610–00 | CAP ASSY | 1 | 1 | 1 | 1 | | |
| 3 | 90445–09220 | HOSE (L30) | 1 | 1 | 1 | 1 | | |
| 4 | 3XJ–24380–00 | PIPE JOINT ASSY | 1 | 1 | 1 | 1 | | |
| 5 | 90445–09251 | HOSE (L350) | 1 | 1 | 1 | 1 | | |
| 6 | 5XE–24144–00 | HOLDER, DAMPER | 1 | 1 | 1 | 1 | | |
| 7 | 90480–18549 | GROMMET | 1 | 1 | 1 | 1 | | |
| 8 | 90105–06107 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 9 | 90105–06111 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 10 | 90201–06570 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 11 | 3JD–24186–00 | WASHER, SPECIAL | 1 | 1 | 1 | 1 | | |
| 12 | 5UM–2419A–E0 | HOLDER | 1 | 1 | 1 | 1 | | |
| 13 | 90387–06090 | COLLAR | 2 | 2 | 2 | 2 | | |
| 14 | 5XC–24339–90 | GROMMET | 1 | 1 | 1 | 1 | | |
| 15 | 90105–06107 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 16 | 90105–06111 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 17 | 90201–06570 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 18 | 90387–06065 | COLLAR | 1 | 1 | 1 | 1 | | |
| 19 | 4EW–2412F–00 | BRACKET, SEAT | 1 | 1 | 1 | 1 | | |
| 20 | 98702–06025 | SCREW, FLAT HEAD | 1 | 1 | 1 | 1 | | |
| 21 | 5XC–24181–90 | DAMPER, LOCATING 1 | 1 | 1 | 1 | 1 | | |
| 22 | 4JT–24500–10 | FUEL COCK ASSY 1 | 1 | 1 | 1 | 1 | | |
| 23 | 3AJ–24534–01 | .SEAL, COCK | 1 | 1 | 1 | 1 | | |
| 24 | 98502–03008 | .SCREW, PAN HEAD | 2 | 2 | 2 | 2 | | |
| 25 | 4X8–24512–00 | .O-RING | 1 | 1 | 1 | 1 | | |
| 26 | 3AC–24523–00 | .VALVE PACKING | 1 | 1 | 1 | 1 | | |
| 27 | 5XC–24311–G0 | PIPE, FUEL 1 | 1 | 1 | 1 | 1 | | |




## FIG. 26 FUEL TANK

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | 90467–100A1 | CLIP | 2 | 2 | 2 | 2 | | |
| 29 | 90202–05193 | WASHER, PLATE | 2 | 2 | 2 | 2 | | |
| 30 | 90149–06108 | SCREW | 2 | 2 | 2 | 2 | | |
| 31 | 5XC–24182–90 | DAMPER, LOCATING 2 | 1 | 1 | 1 | 1 | | |
| 32 | 5XC–24183–90 | DAMPER, LOCATING 3 | 2 | 2 | 2 | 2 | | |
| 33 | 90465–13275 | CLAMP | 3 | 3 | 3 | 3 | | |









5XC9100-E270

## FIG. 27 SEAT

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 2S2–24710–70 | SINGLE SEAT ASSY | 1 | | 1 | 1 | | UR FOR DPBSE |
| | 2S2–24710–80 | SINGLE SEAT ASSY | 1 | | 1 | 1 | | UR FOR PWS1 |
| | 5XC–24710–A0 | SINGLE SEAT ASSY | | 1 | | | | UR FOR DPBSE |
| | 5XC–24710–B0 | SINGLE SEAT ASSY | | 1 | | | | UR FOR PWS1 |
| 2 | 5XC–2470F–90 | .SEAT COVER COMP. | 1 | | 1 | 1 | | UR FOR DPBSE |
| | 2S2–2470F–80 | .SEAT COVER COMP. | 1 | | 1 | 1 | | UR FOR PWS1 |
| | 5XC–2470F–A0 | .SEAT COVER COMP. | | 1 | | | | UR FOR DPBSE |
| | 5XC–2470F–B0 | .SEAT COVER COMP. | | 1 | | | | UR FOR PWS1 |





5XD5100-D280


## FIG. 28 FRONT WHEEL

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5NY–25111–00 | HUB, FRONT | 1 | 1 | 1 | 1 | | |
| 2 | 93306–90409 | BEARING | 2 | 2 | 2 | 2 | | |
| 3 | 5NY–25117–00 | SPACER, BEARING | 1 | 1 | 1 | 1 | | |
| 4 | 93102–26468 | OIL SEAL | 2 | 2 | 2 | 2 | | |
| 5 | 94416–21034 | RIM (1.60-21) | 1 | 1 | 1 | 1 | | |
| 6 | 5NY–25104–00 | SPOKE SET, FRONT | 1 | 1 | 1 | 1 | | |
| 7 | 94108–21015 | TIRE (80/100-21 51M D739FA) | 1 | | | 1 | | DUNLOP |
| | * | TIRE (80/100-21 51R MT320) | | 1 | | | | LM PIRELLI |
| | 94108–2112Y | TIRE (80/100-21 51M D755F) | | 1 | | | | DUNLOP |
| | 94108–21012 | TIRE(80/100-21 51M M601) | | | 1 | | | BRIDGESTONE |
| 8 | 94227–21101 | TUBE (80/100-21 M/C TR4) | 1 | 1 | | 1 | | DUNLOP |
| | * | TUBE (80/100-21) | | 1 | | | | LM PIRELLI |
| | 94209–21229 | TUBE (80/100-21 M/C TR4) | | | 1 | | | BRIDGESTONE |
| 9 | 94309–21161 | BAND, RIM (1.60-21) | 1 | 1 | | 1 | | DUNLOP |
| | * | BAND, RIM (80/100-21) | | 1 | | | | LM PIRELLI |
| | 94330–21084 | BAND,RIM (1.60-21) | | | 1 | | | BRIDGESTONE |
| 10 | 5SF–25394–00 | SPACER, BEAD | 1 | 1 | 1 | 1 | | |
| 11 | 5XC–25181–G0 | AXLE, WHEEL | 1 | 1 | 1 | 1 | | |
| 12 | 5XC–25183–G0 | COLLAR, WHEEL | 1 | 1 | 1 | 1 | | |
| 13 | 5XC–25186–G0 | COLLAR, WHEEL | 1 | 1 | 1 | 1 | | |
| 14 | 90179–16011 | NUT | 1 | 1 | 1 | 1 | | |




## FIG. 29 FRONT BRAKE CALIPER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–2581T–G0 | DISK BRAKE ASSY | 1 | 1 | 1 | 1 | | |
| 2 | 90149–06327 | SCREW | 6 | 6 | 6 | 6 | | |
| 3 | 5XC–2580T–G0 | CALIPER ASSY (LEFT) | 1 | 1 | 1 | 1 | | |
| 4 | 5XC–W0057–00 | .PISTON ASSY, CALIPER | 1 | 1 | 1 | 1 | | |
| 5 | 5KM–W0047–10 | ..CALIPER SEAL KIT | 1 | 1 | 1 | 1 | | |
| 6 | 5DH–25919–00 | .SUPPORT, PAD | 1 | 1 | 1 | 1 | | |
| 7 | 1UY–W0048–50 | .BLEED SCREW KIT | 1 | 1 | 1 | 1 | | |
| 8 | 5XC–W0045–00 | .BRAKE PAD KIT | 1 | 1 | 1 | 1 | | |
| 9 | 5DH–25933–00 | .PIN, PAD | 1 | 1 | 1 | 1 | | |
| 10 | 5DH–25916–00 | .PLUG | 1 | 1 | 1 | 1 | | |
| 11 | 3SP–25926–51 | .BOLT | 1 | 1 | 1 | 1 | | |
| 12 | 3SP–25914–51 | .PIN, SLIDE | 1 | 1 | 1 | 1 | | |
| 13 | 3JD–25917–00 | .BOOT, CALIPER | 1 | 1 | 1 | 1 | | |
| 14 | 1UY–25937–51 | .BOOT 2 | 1 | 1 | 1 | 1 | | |
| 15 | 5XC–25849–G0 | .RETAINER, CALIPER | 1 | 1 | 1 | 1 | | |
| 16 | 90105–08137 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |








5XC9100-E300

## FIG. 30 REAR WHEEL

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5ET–25311–00 | HUB, REAR | 1 | 1 | 1 | 1 | | |
| 2 | 5ET–25317–00 | SPACER, BEARING | 1 | 1 | 1 | 1 | | |
| 3 | 93306–27212 | BEARING | 1 | 1 | 1 | 1 | | |
| 4 | 93306–07202 | BEARING | 1 | 1 | 1 | 1 | | |
| 5 | 93106–30001 | OIL SEAL | 1 | 1 | 1 | 1 | | |
| 6 | 93106–30045 | OIL SEAL | 1 | 1 | 1 | 1 | | |
| 7 | 99009–45500 | CIRCLIP | 1 | 1 | 1 | 1 | | |
| 8 | 94418–19008 | RIM (1.85-19) | 1 | 1 | 1 | 1 | | |
| 9 | 5HD–25304–00 | SPOKE SET, REAR | 1 | 1 | 1 | 1 | | |
| 10 | 94110–19012 | TIRE (100/90-19 57M D756) | 1 | | | 1 | | |
| | * | TIRE (100/90-19 MT320) | | 1 | | | | LM PIRELLI |
| | 94110–1913B | TIRE (100/90-19 57M D755) | | 1 | | | | DUNLOP |
| | 94110–19009 | TIRE(100/90-19 51M M602) | | | 1 | | | BRIDGESTONE |
| 11 | 94210–19224 | TUBE (100/90-19 M/C TR4 BTL) | 1 | 1 | | 1 | | DUNLOP |
| | * | TUBE (110/90-19) | | 1 | | | | LM PIRELLI |
| | 94210–19222 | TUBE (100/90-19 M/C TR4) | | | 1 | | | BRIDGESTONE |
| 12 | 94321–19135 | BAND, RIM (1.85-19) | 1 | 1 | | 1 | | DUNLOP |
| | * | BAND, RIM (3.50-18) | | 1 | | | | LM METZELER |
| | 94316–19156 | BAND, RIM (1.85-19) | | | 1 | | | BRIDGESTONE |
| 13 | 4XM–25394–00 | SPACER, BEAD | 1 | 1 | 1 | 1 | | |
| 14 | 4XM–25364–00 | DAMPER | 1 | 1 | 1 | 1 | | |
| 15 | 1C3–25449–00 | SPROCKET, DRIVEN (49T) | 1 | 1 | 1 | 1 | | STD |
| | 1C3–25447–00 | SPROCKET, DRIVEN (47T) | 1 | 1 | 1 | 1 | | AP |
| | 1C3–25448–00 | SPROCKET, DRIVEN (48T) | 1 | 1 | 1 | 1 | | AP |
| | 1C3–25450–00 | SPROCKET, DRIVEN (50T) | 1 | 1 | 1 | 1 | | AP |
| | 1C3–25451–00 | SPROCKET, DRIVEN (51T) | 1 | 1 | 1 | 1 | | AP |
| | 1C3–25452–00 | SPROCKET, DRIVEN (52T) | 1 | 1 | 1 | 1 | | AP |








5XC9100-E300


## FIG. 30 REAR WHEEL

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 16 | 90109–08078 | BOLT | 6 | 6 | 6 | 6 | | |
| 17 | 90185–08008 | NUT, SELF-LOCKING | 6 | 6 | 6 | 6 | | |
| 18 | 90201–08048 | WASHER, PLATE | 6 | 6 | 6 | 6 | | |
| 19 | 90480–08608 | GROMMET | 1 | 1 | 1 | 1 | | |
| 20 | 5TJ–2530S–80 | COLLAR ASSY | 2 | 2 | 2 | 2 | | |
| 21 | 1C3–25388–50 | PULLER, CHAIN 1 | 1 | 1 | 1 | 1 | | |
| 22 | 1C3–25389–00 | PULLER, CHAIN 2 | 1 | 1 | 1 | 1 | | |
| 23 | 90101–08006 | BOLT | 2 | 2 | 2 | 2 | | |
| 24 | 90179–08674 | NUT | 2 | 2 | 2 | 2 | | |
| 25 | 1C3–25381–90 | AXLE, WHEEL | 1 | 1 | 1 | 1 | | |
| 26 | 90185–20002 | NUT, SELF-LOCKING | 1 | 1 | 1 | 1 | | |
| 27 | 90201–20020 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 28 | 9Y581–92111 | CHAIN (DID 520D 112L) | 1 | 1 | 1 | 1 | | |
| 29 | 94681–68001 | .JOINT,CHAIN (DID 520DM-RJ) | 1 | 1 | 1 | 1 | | |





## FIG. 31 REAR BRAKE CALIPER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 2S2–2582W–70 | DISK, REAR BRAKE 2 | 1 | 1 | 1 | 1 | | |
| 2 | 90105–06108 | BOLT, FLANGE | 6 | 6 | 6 | 6 | | |
| 3 | 1C3–2580W–50 | CALIPER ASSY, REAR 2 | 1 | 1 | 1 | 1 | | |
| 4 | 5UN–W0057–50 | .PISTON ASSY, CALIPER | 1 | 1 | 1 | 1 | | |
| 5 | 5UN–W0047–50 | ..CALIPER SEAL KIT | 1 | 1 | 1 | 1 | | |
| 6 | 5DH–25919–50 | .SUPPORT, PAD | 1 | 1 | 1 | 1 | | |
| 7 | 1UY–W0048–50 | .BLEED SCREW KIT | 1 | 1 | 1 | 1 | | |
| 8 | 1C3–W0046–50 | .BRAKE PAD KIT 2 | 1 | 1 | 1 | 1 | | |
| 9 | 5UN–25828–60 | ..SHIM, CALIPER | 1 | 1 | 1 | 1 | | |
| 10 | 5UN–25827–60 | ..SHIM, CALIPER | 1 | 1 | 1 | 1 | | |
| 11 | 5UN–22898–60 | ..INSULATOR, HEAT | 2 | 2 | 2 | 2 | | |
| 12 | 8CR–25924–00 | .PIN, PAD | 1 | 1 | 1 | 1 | | |
| 13 | 5DH–25916–00 | .PLUG | 1 | 1 | 1 | 1 | | |
| 14 | 5DH–25914–50 | .PIN, SLIDE | 1 | 1 | 1 | 1 | | |
| 15 | 3JD–25917–00 | .BOOT, CALIPER | 1 | 1 | 1 | 1 | | |
| 16 | 5UN–25914–00 | .PIN, SLIDE | 1 | 1 | 1 | 1 | | |
| 17 | 1UY–25937–51 | .BOOT 2 | 1 | 1 | 1 | 1 | | |
| 18 | 1C3–25718–50 | PROTECTOR, DISK BRAKE | 1 | 1 | 1 | 1 | | |
| 19 | 90105–06110 | BOLT, FLANGE | 2 | 2 | 2 | 2 | | |
| 20 | 1C3–27491–50 | PROTECTOR | 1 | 1 | 1 | 1 | | |
| 21 | 90105–06107 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |
| 22 | 90105–06111 | BOLT, FLANGE | 1 | 1 | 1 | 1 | | |





## FIG. 32 STEERING HANDLE & CABLE

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 1C3–26111–90 | HANDLEBAR | 1 | 1 | 1 | 1 | | |
| 2 | 4GY–26241–00 | GRIP | 1 | 1 | 1 | 1 | | |
| 3 | 5TJ–26240–C0 | GRIP ASSY | 1 | 1 | 1 | 1 | | |
| 4 | 4GY–26242–00 | .GRIP (RIGHT) | 1 | 1 | 1 | 1 | | |
| 5 | 3Y1–26249–00 | .RING, LEAF | 1 | 1 | 1 | 1 | | |
| 6 | 5BE–26281–00 | CAP, GRIP UPPER | 1 | 1 | 1 | 1 | | |
| 7 | 5BE–26282–00 | CAP, GRIP LOWER | 1 | 1 | 1 | 1 | | |
| 8 | 98502–05020 | SCREW, PAN HEAD | 2 | 2 | 2 | 2 | | |
| 9 | 5SF–26287–10 | COVER, CAP GRIP | 1 | 1 | 1 | 1 | | |
| 10 | 5XC–26302–G0 | THROTTLE CABLE ASSY | 1 | 1 | 1 | 1 | | |
| 11 | 5XC–26335–G0 | CABLE, CLUTCH | 1 | 1 | 1 | 1 | | |
| 12 | 90387–225N2 | COLLAR | 1 | 1 | 1 | 1 | | |
| 13 | 1C3–26342–50 | BOOT, CABLE | 1 | 1 | 1 | 1 | | |
| 14 | 5XC–26124–90 | PROTECTOR, HANDLEBAR | 1 | 1 | 1 | 1 | | |
| 15 | 5XC–26143–90 | COVER, HANDLEBAR UPPER 1 | 1 | 1 | 1 | 1 | | UR FOR DPBSE |
| | 2S2–26143–70 | COVER, HANDLEBAR UPPER 1 | 1 | 1 | 1 | 1 | | UR FOR PWS1 |





## FIG. 33 FRONT MASTER CYLINDER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 1C3–25872–90 | HOSE, BRAKE 1 | 1 | 1 | 1 | 1 | | |
| 2 | 90430–10005 | GASKET | 4 | 4 | 4 | 4 | | |
| 3 | 90401–10172 | BOLT, UNION | 2 | 2 | 2 | 2 | | |
| 4 | 5XC–W2587–00 | MASTER CYLINDER SUB ASSY | 1 | 1 | 1 | 1 | | |
| 5 | 5XC–W0041–00 | .CYLINDER KIT, MASTER | 1 | 1 | 1 | 1 | | |
| 6 | 5XC–25854–G0 | .DIAPHRAGM, RESERVOIR | 1 | 1 | 1 | 1 | | |
| 7 | 5XC–25852–G0 | .CAP, RESERVOIR | 1 | 1 | 1 | 1 | | |
| 8 | 98706–04012 | .SCREW, FLAT HEAD | 2 | 2 | 2 | 2 | | |
| 9 | 5CG–25715–00 | .SEPARATOR ASSY | 1 | 1 | 1 | 1 | | |
| 10 | 5XC–25853–G0 | .FLOAT, RESERVOIR | 1 | 1 | 1 | 1 | | |
| 11 | 5XC–83922–G0 | LEVER 2 | 1 | 1 | 1 | 1 | | |
| 12 | 5MV–2589F–00 | BOLT, LEVER | 1 | 1 | 1 | 1 | | |
| 13 | 95701–06500 | NUT, FLANGE | 1 | 1 | 1 | 1 | | |
| 14 | 5MV–25867–00 | BRACKET, MASTER CYLINDER | 1 | 1 | 1 | 1 | | |
| 15 | 5MV–25833–00 | BOLT, FITTING | 2 | 2 | 2 | 2 | | |
| 16 | 5XC–26372–G0 | COVER, HANDLE LEVER 1 | 1 | 1 | 1 | 1 | | |





## FIG. 34 STAND & FOOTREST

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5UM–27200–00 | PEDAL, BRAKE | 1 | 1 | 1 | 1 | | |
| 2 | 5XC–27217–90 | BOLT | 1 | 1 | 1 | 1 | | |
| 3 | 93210–11073 | O-RING | 2 | 2 | 2 | 2 | | |
| 4 | 91402–20012 | PIN, COTTER | 1 | 1 | 1 | 1 | | |
| 5 | 90506–16007 | SPRING, TENSION | 1 | 1 | 1 | 1 | | |
| 6 | 90240–08120 | PIN, CLEVIS | 1 | 1 | 1 | 1 | | |
| 7 | 90201–08044 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |
| 8 | 90468–16001 | CLIP | 1 | 1 | 1 | 1 | | |
| 9 | 5XE–27411–01 | FOOTREST 1 | 1 | 1 | 1 | 1 | | |
| 10 | 5XE–27421–01 | FOOTREST 2 | 1 | 1 | 1 | 1 | | |
| 11 | 90240–10004 | PIN, CLEVIS | 2 | 2 | 2 | 2 | | |
| 12 | 91402–25015 | PIN, COTTER | 2 | 2 | 2 | 2 | | |
| 13 | 90508–28015 | SPRING, TORSION | 1 | 1 | 1 | 1 | | |
| 14 | 90508–28018 | SPRING, TORSION | 1 | 1 | 1 | 1 | | |
| 15 | 1C3–27311–00 | STAND, SIDE | 1 | 1 | 1 | 1 | | |
| 16 | 90201–10032 | WASHER, PLATE | 2 | 2 | 2 | 2 | | |




## FIG. 35 REAR MASTER CYLINDER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 1C3–2583V–00 | RR. MASTER CYLINDER ASSY. | 1 | 1 | 1 | 1 | | |
| 2 | 5UN–W0042–50 | .CYLINDER KIT, MASTER | 1 | 1 | 1 | 1 | | |
| 3 | 5UN–27218–00 | .NUT | 1 | 1 | 1 | 1 | | |
| 4 | 5UN–27222–00 | .JOINT | 1 | 1 | 1 | 1 | | |
| 5 | 5UN–25852–50 | .CAP, RESERVOIR | 1 | 1 | 1 | 1 | | |
| 6 | 5UN–2585B–00 | .PLATE, DIAPHRAGM | 1 | 1 | 1 | 1 | | |
| 7 | 5UN–25854–00 | .DIAPHRAGM, RESERVOIR | 1 | 1 | 1 | 1 | | |
| 8 | 5UN–27217–00 | .BOLT | 2 | 2 | 2 | 2 | | |
| 9 | 5CG–25715–00 | .SEPARATOR ASSY | 1 | 1 | 1 | 1 | | |
| 10 | 90111–06059 | BOLT,HEX. SOCKET BUTTON | 2 | 2 | 2 | 2 | | |
| 11 | 1C3–25873–00 | HOSE, BRAKE 2 | 1 | 1 | 1 | 1 | | |
| 12 | 90401–10172 | BOLT, UNION | 2 | 2 | 2 | 2 | | |
| 13 | 90430–10005 | GASKET | 4 | 4 | 4 | 4 | | |
| 14 | 1C3–25886–50 | HOLDER, BRAKE HOSE | 1 | 1 | 1 | 1 | | |
| 15 | 98502–05010 | SCREW, PAN HEAD | 4 | 4 | 4 | 4 | | |
| 16 | 1C3–25876–50 | HOLDER, BRAKE HOSE 2 | 1 | 1 | 1 | 1 | | |








5TA1100-B360


## FIG. 36 GENERATOR

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–85560–00 | BASE ASSY | 1 | 1 | 1 | 1 | | |
| 2 | 5TA–85550–00 | ROTOR ASSY | 1 | 1 | 1 | 1 | | |
| 3 | 90149–06121 | SCREW | 3 | 3 | 3 | 3 | | |
| 4 | 90179–12657 | NUT | 1 | 1 | 1 | 1 | | |
| 5 | 90201–127E1 | WASHER, PLATE | 1 | 1 | 1 | 1 | | |





## FIG. 37 HANDLE SWITCH & LEVER

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XE–82911–00 | HOLDER, LEVER 1 | 1 | 1 | 1 | 1 | | |
| 2 | 5MV–83912–00 | LEVER 1 | 1 | 1 | 1 | 1 | | |
| 3 | 90109–06034 | BOLT | 1 | 1 | 1 | 1 | | |
| 4 | 5LP–84126–10 | NUT, LENS FITTING | 1 | 1 | 1 | 1 | | |
| 5 | 5HD–26337–00 | BOLT, ADJUSTING | 1 | 1 | 1 | 1 | | |
| 6 | 5HD–83951–00 | BOLT, CABLE ADJUSTING | 1 | 1 | 1 | 1 | | |
| 7 | 5HD–26372–00 | COVER, HANDLE LEVER 1 | 1 | 1 | 1 | 1 | | |
| 8 | 5XD–82946–00 | HOLDER, STARTER LEVER | 1 | 1 | 1 | 1 | | |
| 9 | 5XD–82913–00 | HOLDER, LEVER LOWER 1 | 1 | 1 | 1 | 1 | | |
| 10 | 5TA–83941–00 | LEVER, STARTER | 1 | 1 | 1 | 1 | | |
| 11 | 5XC–26334–G0 | CABLE, STARTER 2 | 1 | 1 | 1 | 1 | | |
| 12 | 97002–05016 | BOLT | 2 | 2 | 2 | 2 | | |
| 13 | 92012–05012 | BOLT, BUTTON HEAD | 2 | 2 | 2 | 2 | | |
| 14 | 95602–05100 | NUT, U | 1 | 1 | 1 | 1 | | |
| 15 | 90149–05162 | SCREW | 1 | 1 | 1 | 1 | | |
| 16 | 5TA–26339–00 | BOOT | 1 | 1 | 1 | 1 | | |
| 17 | 1C3–83976–00 | SWITCH, HANDLE 1 | 1 | 1 | 1 | 1 | | |




## FIG. 38 ELECTRICAL 1

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–85540–G0 | C.D.I. UNIT ASSY | 1 | 1 | 1 | 1 | | |
| 2 | 1C3–85546–00 | BAND | 1 | 1 | 1 | 1 | | |
| 3 | 5UL–82310–10 | IGNITION COIL ASSY | 1 | 1 | 1 | 1 | | |
| 4 | 5XC–82540–00 | NEUTRAL SWITCH ASSY | 1 | 1 | 1 | 1 | | |
| 5 | 93210–21276 | O-RING | 1 | 1 | 1 | 1 | | |
| 6 | 90154–05022 | SCREW, BINDING | 2 | 2 | 2 | 2 | | |
| 7 | 90464–13077 | CLAMP | 1 | 1 | 1 | 1 | | |
| 8 | 90464–13073 | CLAMP | 1 | 1 | 1 | 1 | | |
| 9 | 90464–15195 | CLAMP | 1 | 1 | 1 | 1 | | |
| 10 | 5Y9–12491–00 | CLAMP 1 | 1 | 1 | 1 | 1 | | |
| 11 | 90465–13275 | CLAMP | 4 | 4 | 4 | 4 | | |
| 12 | 5Y9–12491–00 | CLAMP 1 | 2 | 2 | 2 | 2 | | |
| 13 | 90465–13275 | CLAMP | 1 | 1 | 1 | 1 | | |
| 14 | 5XC–82509–00 | WIRE, SUB LEAD | 1 | 1 | 1 | 1 | | |








5XC9100-E390

## FIG. 39 ALTERNATE FOR CHASSIS

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5UN–22212–00 | SPRING (K=42N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 1C3–22212–00 | SPRING (K=44N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 1C3–22212–10 | SPRING (K=46N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 1C3–22212–30 | SPRING (K=50N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 1C3–22212–40 | SPRING (K=52N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 1C3–22212–50 | SPRING (K=54N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 1C3–22212–60 | SPRING (K=55.8N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 5UN–22212–A0 | SPRING (K=APPROX.44N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 5UN–22212–B0 | SPRING (K=APPROX.46N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 5UN–22212–C0 | SPRING (K=APPROX.48N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 5UN–22212–D0 | SPRING (K=APPROX.50N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 5UN–22212–E0 | SPRING (K=APPROX.52N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 5UN–22212–F0 | SPRING (K=APPROX.54N/MM) | 1 | 1 | 1 | 1 | | AP |
| | 5UN–22212–G0 | SPRING (K=APPROX.56N/MM) | 1 | 1 | 1 | 1 | | AP |
| 2 | 1C3–23141–A1 | SPRING, FRONT FORK(K=3.9N/MM) | 2 | 2 | 2 | 2 | | AP |
| | 1C3–23141–B1 | SPRING, FRONT FORK(K=4.0N/MM) | 2 | 2 | 2 | 2 | | AP |
| | 1C3–23141–C1 | SPRING, FRONT FORK(K=4.1N/MM) | 2 | 2 | 2 | 2 | | AP |
| | 1C3–23141–E1 | SPRING, FRONT FORK(K=4.3N/MM) | 2 | 2 | 2 | 2 | | AP |
| | 1C3–23141–F1 | SPRING, FRONT FORK(K=4.4N/MM) | 2 | 2 | 2 | 2 | | AP |
| | 1C3–23141–G1 | SPRING, FRONT FORK(K=4.5N/MM) | 2 | 2 | 2 | 2 | | AP |
| | 1C3–23141–H1 | SPRING, FRONT FORK(K=4.6N/MM) | 2 | 2 | 2 | 2 | | AP |
| | 1C3–23141–J1 | SPRING, FRONT FORK(K=4.7N/MM) | 2 | 2 | 2 | 2 | | AP |







5XCB010-E400

## FIG. 40 ALTERNATE

| REF. NO. | PART NO. | DESCRIPTION | 5XCG | 5XCH | 5XCJ | 5XCK | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 5XC–14750–50 | SILENCER ASSY | | | 1 | | | AP |
| 2 | 90267–48084 | .RIVET, BLIND | | | 16 | | | |
| 3 | 5XC–1469A–10 | .FIBER | | | 1 | | | |
| 4 | 2S2–1469E–00 | .FIBER | | | 1 | | | |
| 5 | 2S2–1469F–00 | .FIBER | | | 1 | | | |
| 6 | 5XD–14714–00 | .GASKET, MUFFLER | | | 1 | | | |
| 7 | 5BE–14747–00 | .DAMPER, MUFFLER | | | 1 | | | |
| 8 | 90387–08081 | .COLLAR | | | 1 | | | |

# NUMERICAL INDEX


| PART NO. | GRID NO. |
|---|---|
| 5XC–11102–20 | B – 2 |
| 5XC–11133–10 | B – 2 |
| 5NL–11134–10 | B – 2 |
| 5XC–11166–00 | B – 2 |
| 371–11167–01 | B – 2 |
| 5NL–11181–00 | B – 2 |
| 5NL–11191–20 | B – 2 |
| 5NL–11193–00 | B – 2 |
| 5UM–1119E–00 | B – 2 |
| 5XC–11311–10 | B – 3 |
| 5NL–11351–00 | B – 3 |
| 5XC–11400–20 | B – 4 |
| 5UL–11412–20 | B – 4 |
| 5UL–11422–10 | B – 4 |
| 5NL–11454–00 | B – 4 |
| 5NL–11455–00 | B – 4 |
| 5NL–11531–00 | B – 4 |
| 5NL–11536–00 | B – 4 |
| 5NL–11603–00 | B – 4 |
| 5NL–11631–20 | B – 4 |
| 5NL–11633–00 | B – 4 |
| 5XC–11651–00 | B – 4 |
| 5XC–11681–00 | B – 4 |
| 5NL–12111–20 | B – 5 |
| 5NL–12112–20 | B – 5 |
| 5NL–12113–00 | B – 5 |
| 5NL–12114–00 | B – 5 |
| 5NL–12116–00 | B – 5 |
| 1HX–12117–00 | B – 5 |
| 1WG–12117–00 | B – 5 |
| 1HX–12118–00 | B – 5 |
| 1WG–12118–00 | B – 5 |
| 4SV–12119–00 | B – 5 |
| 4TV–12119–00 | B – 5 |
| 5NL–12121–10 | B – 5 |
| 3GM–12126–00 | B – 5 |
| 3FV–12153–10 | B – 6 |
| 3LN–12153–10 | B – 6 |
| 1HX–12168–00 | B – 5 |
| 1HX–12168–20 | B – 5 |
| 1HX–12168–40 | B – 5 |
| 1HX–12168–60 | B – 5 |
| 1HX–12168–80 | B – 5 |
| 1HX–12168–A0 | B – 5 |
| 1HX–12168–F0 | B – 5 |
| 1HX–12168–H1 | B – 5 |
| 1HX–12168–K1 | B – 5 |
| 1HX–12168–M1 | B – 5 |
| 1HX–12168–R1 | B – 5 |
| 1HX–12168–U1 | B – 5 |
| 1HX–12168–W1 | B – 5 |
| 1HX–12168–Y1 | B – 5 |
| 1HX–12169–11 | B – 6 |
| 1HX–12169–31 | B – 6 |
| 1HX–12169–50 | B – 6 |
| 1HX–12169–70 | B – 6 |
| 1HX–12169–90 | B – 6 |
| 1HX–12169–E0 | B – 6 |
| 1HX–12169–G0 | B – 6 |
| 1HX–12169–J0 | B – 6 |
| 1HX–12169–L0 | B – 6 |
| 1HX–12169–N0 | B – 6 |
| 1HX–12169–T0 | B – 6 |
| 5UL–12170–10 | B – 7 |
| 5UL–12180–10 | B – 7 |
| 5TA–12210–20 | B – 7 |
| 4FM–12213–00 | B – 7 |
| 5BE–12241–00 | B – 7 |
| 5NL–12251–10 | B – 7 |
| 5NL–12252–00 | B – 7 |
| 5XC–1240A–G0 | B – 9 |
| 5NL–12422–10 | B – 8 |
| 5NL–12439–00 | B – 8 |
| 5DH–12451–00 | B – 8 |
| 5XC–12459–00 | B – 8 |
| 5XC–12461–G0 | B – 9 |
| 22W–12462–00 | B – 9 |
| 2S2–12464–70 | B – 9 |
| 5XC–12481–G0 | B – 9 |
| 1C3–12482–00 | B – 9 |
| 5Y9–12491–00 | E – 15 |
| 5NL–12564–00 | C – 6 |
| 5XC–12576–G0 | B – 9 |
| 5XC–12578–G0 | B – 9 |
| 5XC–12579–G0 | B – 9 |
| 583–13113–00 | B – 12 |
| 5NL–13161–20 | B – 12 |
| 5NL–13171–00 | B – 12 |
| 5SG–13300–00 | B – 10 |
| 5NL–13320–00 | B – 10 |
| 5NL–13341–00 | B – 10 |
| 5BE–13342–00 | B – 10 |
| 5NL–13411–00 | B – 10 |
| 5XC–13412–00 | B – 10 |
| 5XC–13416–90 | D – 5 |
| 5TA–13440–00 | B – 12 |
| 5BE–13447–10 | B – 12 |
| 5XC–13464–30 | B – 10 |
| 5XC–13465–30 | B – 10 |
| 5XC–13597–30 | B – 13 |
| 5XC–14101–G0 | B – 14 |
| 5XC–14101–H0 | B – 14 |
| 5NL–14105–00 | C – 2 |
| 4MX–14115–00 | C – 3 |
| 3TJ–14137–40 | B – 13 |
| | C – 3 |
| 5BE–14146–00 | C – 3 |
| 5PA–14146–00 | C – 3 |
| 5TA–14155–00 | C – 2 |
| 633–14159–00 | C – 2 |
| 3TJ–14159–40 | B – 14 |
| 5XC–14171–00 | C – 2 |
| 3TJ–14191–40 | C – 2 |
| 5UL–14196–00 | C – 3 |
| 5TA–14197–00 | C – 3 |
| 5NX–14216–00 | C – 3 |
| 5TA–14227–00 | B – 13 |
| 5TA–14239–00 | B – 13 |
| 5TA–14261–00 | C – 3 |
| 5JG–14264–00 | B – 14 |
| 3TJ–14267–40 | B – 14 |
| 5JG–14275–00 | B – 14 |
| 5TA–14293–00 | B – 13 |
| 3TJ–14293–40 | C – 2 |
| 5XD–14325–00 | C – 3 |
| 5TA–14335–00 | C – 2 |
| 5JG–14346–00 | C – 3 |
| 5TA–14371–00 | C – 2 |
| 2S2–14374–00 | C – 2 |
| 5JG–14379–00 | C – 2 |
| 2S2–14388–00 | B – 14 |
| 4MX–14392–00 | C – 2 |
| 2S2–14401–70 | B – 13 |
| 5XC–14417–90 | B – 13 |
| 5NY–14442–00 | B – 13 |
| 4XM–14451–00 | B – 13 |
| 5XC–14453–G0 | B – 13 |
| 5NY–14455–20 | B – 13 |
| 5BE–14458–00 | B – 13 |
| 5NY–14459–00 | B – 13 |
| 5JG–14521–00 | B – 14 |
| 5JG–14522–00 | B – 14 |
| 5JG–14531–00 | C – 3 |
| 3TJ–14536–40 | C – 2 |
| 5JG–14546–01 | B – 14 |
| 676–14548–00 | C – 2 |
| 4MX–14561–00 | C – 3 |
| 6H4–14561–00 | C – 2 |
| 5NX–14562–00 | C – 3 |
| 3TJ–14564–40 | C – 2 |
| 5JG–14565–00 | C – 3 |
| 5NL–14591–00 | C – 3 |
| 688–14592–00 | B – 14 |
| 5XC–14611–20 | C – 4 |
| 5NL–14613–00 | C – 4 |
| 5XC–14628–00 | C – 4 |
| 5XC–1469A–00 | C – 4 |
| 5XC–1469A–10 | C – 4 |
| | F – 3 |
| 2S2–1469E–00 | C – 4 |
| | F – 3 |
| 2S2–1469F–00 | C – 4 |
| | F – 3 |
| 5XD–14714–00 | C – 4 |
| | F – 3 |
| 5BE–14747–00 | C – 4 |
| | F – 3 |
| 5XC–14750–30 | C – 4 |
| 5XC–14750–40 | C – 4 |
| 5XC–14750–50 | F – 3 |
| 4BD–14766–00 | C – 4 |
| 5BE–14788–00 | C – 4 |
| 5NL–14916–P1 | B – 14 |
| 5NL–14916–PM | B – 14 |
| 5NL–14916–PN | B – 14 |
| 5NL–14916–PP | B – 14 |
| 5NL–14916–PR | B – 14 |
| 5NL–14916–PS | B – 14 |
| 5NL–14916–PT | B – 14 |
| 5XC–14922–00 | C – 2 |
| 3TJ–14933–40 | C – 2 |
| 5TA–14934–00 | C – 3 |
| 5JG–14940–16 | C – 2 |
| 5JG–14940–17 | C – 2 |
| 5JG–14940–18 | C – 2 |
| 5JG–14940–76 | C – 2 |
| 5TA–14943–28 | C – 2 |
| 4MX–14943–41 | B – 14 |
| 4MX–14943–42 | B – 15 |
| 4MX–14943–43 | B – 15 |
| 4MX–14943–44 | B – 15 |
| 4MX–14943–91 | B – 14 |
| 4MX–14943–92 | B – 15 |
| 4MX–14943–93 | B – 14 |
| 4MX–14943–94 | B – 15 |
| 4MX–14943–95 | B – 15 |
| 5XC–14947–00 | B – 14 |
| 4MX–14948–02 | B – 15 |
| 4MX–14948–03 | B – 15 |
| 4MX–14948–04 | B – 15 |
| 4MX–14948–05 | B – 15 |
| 4MX–14948–06 | B – 15 |
| 4JT–1494F–03 | B – 15 |
| 4JT–1494F–07 | B – 15 |
| 4JT–1494F–11 | B – 15 |
| 3TJ–1494F–13 | B – 15 |
| 3TJ–1494F–14 | B – 15 |
| 3TJ–1494F–15 | B – 15 |
| 4JT–1494F–15 | B – 15 |
| 3TJ–1494F–16 | B – 15 |
| 3TJ–1494F–17 | B – 15 |
| 3TJ–1494F–18 | B – 15 |
| 3TJ–1494F–19 | B – 15 |
| 4JT–1494F–19 | B – 15 |
| 4JT–1494F–23 | B – 15 |
| 4JT–1494F–27 | B – 15 |
| 4JT–1494F–29 | C – 2 |
| 5JG–14951–00 | B – 14 |
| 5JG–14959–00 | B – 14 |
| 5JG–14984–00 | C – 2 |
| 4SR–14985–00 | C – 2 |
| 5TA–14987–00 | B – 13 |
| 5TJ–14987–00 | C – 3 |
| 5TA–14991–00 | C – 2 |
| 4FN–14997–00 | B – 14 |
| 5TA–14997–00 | C – 2 |
| 5XC–15118–00 | C – 7 |
| 5XC–15150–20–YX | C – 5 |
| 3Y1–15361–00 | C – 7 |
| 3Y1–15363–00 | C – 6 |
| 5XC–15373–00 | C – 6 |
| 2S2–15378–00 | C – 7 |
| 4JT–15381–01 | C – 5 |
| 5BE–15383–01 | C – 5 |
| 5NL–15388–00 | C – 5 |
| 5NL–15411–20 | C – 6 |
| 5NL–15415–10 | C – 6 |
| 5BE–15421–10 | C – 5 |
| 5XC–15431–01 | C – 6 |
| 5NL–15441–01 | C – 5 |
| 5NL–15451–00 | C – 6 |
| 5NL–15453–10 | C – 6 |
| 5NL–15462–00 | C – 6 |
| 5NL–15601–20 | C – 8 |
| 5XC–15620–10 | C – 8 |
| 5XC–15621–10 | C – 8 |
| 5NL–15641–20 | C – 8 |
| 5NL–15651–00 | C – 8 |
| 5NL–15664–00 | C – 8 |
| 5SG–15668–00 | C – 8 |
| 2S2–15671–00 | C – 8 |
| 214–15686–00 | C – 8 |
| 5NL–16111–00 | C – 9 |
| 5NL–16150–10 | C – 9 |
| 5NL–16154–00 | C – 9 |
| 3XJ–16321–00 | C – 9 |
| 5DH–16321–00 | C – 9 |
| 5NL–16325–00 | C – 9 |
| 5NL–16325–10 | C – 9 |
| 5HD–16351–00 | C – 9 |
| 5NL–16356–00 | C – 9 |
| 5NL–16357–10 | C – 9 |
| 5NL–16371–00 | C – 9 |
| 5JG–16381–10 | C – 9 |
| 5NL–16383–10 | C – 9 |
| 4JT–16384–00 | C – 9 |
| 5NL–16384–00 | C – 9 |
| 5NL–17121–00 | C – 11 |
| 5NL–17131–10 | C – 11 |
| 5NL–17141–11 | C – 11 |
| 5NL–17151–00 | C – 11 |
| 5NL–17211–10 | C – 11 |
| 5NL–17221–00 | C – 11 |
| 5NL–17231–11 | C – 11 |
| 5NL–17241–11 | C – 11 |
| 5NL–17251–10 | C – 11 |
| 5NL–17402–00 | C – 11 |
| 5NL–17411–10 | C – 11 |
| 5NL–17466–00 | C – 5 |
| 5NL–17471–10 | C – 12 |
| 5UL–18101–10 | C – 14 |
| 5XC–18110–00 | C – 14 |
| 5LP–18122–01 | C – 14 |
| 3XK–18140–00 | C – 13 |
| 5BE–18172–00 | C – 14 |
| 3XJ–18173–10 | C – 14 |
| 3XJ–18178–00 | C – 14 |
| 3XJ–18182–00 | C – 14 |

| PART NO. | GRID NO. |
|---|---|
| 3XJ–18184–00 | C – 14 |
| 2S2–18185–00 | C – 14 |
| 5NL–18501–00 | C – 13 |
| 5NL–18502–00 | C – 13 |
| 5NL–18503–00 | C – 13 |
| 5NL–18541–00 | C – 13 |
| 4UN–18542–00 | C – 13 |
| 5DH–18562–00 | C – 5 |
| 5XC–21101–G0 | C – 15 |
| 5XC–21163–90 | D – 2 |
| 5XC–21164–90 | D – 2 |
| 5PA–2118K–00 | D – 3 |
| 5PA–2118K–10 | D – 3 |
| 5PA–2118K–20 | D – 3 |
| 2S2–21190–70 | C – 15 |
| 1C3–21244–10 | D – 2 |
| 5XC–21274–90 | D – 2 |
| 5XC–21288–90 | D – 2 |
| 1C3–2135F–00 | D – 8 |
| 1C3–2139R–00 | D – 8 |
| 5XC–21417–G0 | D – 2 |
| 5XC–21418–G0 | D – 2 |
| 5XC–21425–G0 | C – 15 |
| 5XC–21426–G0 | C – 15 |
| 1C3–21447–10 | C – 15 |
| 1C3–21448–10 | C – 15 |
| 5XC–21456–90 | D – 2 |
| 5XC–21471–90 | D – 2 |
| 5XC–2147E–G0 | D – 2 |
| 5XC–21486–90 | D – 2 |
| 1C3–21511–51 | D – 3 |
| 2S2–21511–70 | D – 3 |
| 4LB–2151H–02 | D – 3 |
| 3XJ–2151H–A1 | D – 3 |
| 3XJ–2151H–B1 | D – 4 |
| 4XL–2153A–10 | D – 14 |
| 5XC–2153E–00 | D – 3 |
| 4ES–2153E–01 | D – 3 |
| 5XC–2153E–10 | D – 3 |
| 4ES–2153E–20 | D – 3 |
| 5PA–21568–00 | D – 4 |
| 2S2–21610–70 | D – 3 |
| 5XC–21610–90 | D – 3 |
| 5XE–21635–10 | D – 3 |
| 5XC–2163G–10 | D – 4 |
| 5TA–21642–00 | D – 3 |
| 2S2–2165A–00 | D – 4 |
| 3RV–21668–A0 | D – 8 |

| PART NO. | GRID NO. |
|---|---|
| 3RV–21668–B0 | D – 8 |
| 5XC–21710–90 | D – 5 |
| 5XC–21720–90 | D – 5 |
| 2S2–2172A–70 | D – 5 |
| 2S2–2172A–80 | D – 5 |
| 2S2–21730–70 | D – 5 |
| 5XC–21730–90 | D – 5 |
| 5XC–2173E–10 | D – 5 |
| 5XC–2173F–10 | D – 5 |
| 5XC–2173L–10 | D – 5 |
| 2S2–21740–70 | D – 5 |
| 5XC–21740–90 | D – 5 |
| 5XC–2174L–10 | D – 5 |
| 5XC–21751–G0 | D – 5 |
| 2S2–22110–70 | D – 7 |
| 5XC–22121–91 | D – 8 |
| 1C3–22122–00 | D – 8 |
| 2S2–22128–70 | D – 7 |
| 1C3–22141–10 | D – 7 |
| 2S2–22151–70 | D – 7 |
| 5UN–22176–00 | D – 9 |
| 30X–22178–00 | C – 15 |
| 3JD–22178–20 | C – 15 |
| 5XC–2217A–G0 | D – 7 |
| 5XC–2217F–G0 | D – 7 |
| 4V4–22184–00 | C – 15 |
| 5MV–22184–00 | D – 9 |
| 2S2–22199–70 | D – 7 |
| 5XC–22200–G0 | D – 9 |
| 5XC–22200–H0 | D – 9 |
| 5XC–22200–J0 | D – 9 |
| 5XC–22200–K0 | D – 9 |
| 5XC–22200–L0 | D – 9 |
| 5XC–22201–G0 | D – 9 |
| 5XC–22201–H0 | D – 9 |
| 1C3–22212–00 | F – 2 |
| 5UN–22212–00 | F – 2 |
| 1C3–22212–10 | F – 2 |
| 1C3–22212–20 | D – 9 |
| 1C3–22212–30 | F – 2 |
| 1C3–22212–40 | F – 2 |
| 1C3–22212–50 | F – 2 |
| 1C3–22212–60 | F – 2 |
| 5UN–22212–A0 | F – 2 |
| 5UN–22212–B0 | F – 2 |
| 5UN–22212–C0 | F – 2 |
| 5UN–22212–D0 | F – 2 |
| 5UN–22212–E0 | F – 2 |

| PART NO. | GRID NO. |
|---|---|
| 5UN–22212–F0 | F – 2 |
| 5UN–22212–G0 | F – 2 |
| 1C3–22213–L0 | D – 9 |
| 1C3–22214–50 | D – 9 |
| 5MV–22224–00 | D – 9 |
| 4JX–22226–00 | D – 9 |
| 3SP–22234–00 | D – 9 |
| 5NY–22241–00 | D – 10 |
| 5XE–22242–00 | D – 10 |
| 1C3–22253–50 | D – 9 |
| 1C3–22253–L0 | D – 9 |
| 4AA–22259–40 | D – 9 |
| 4AA–22259–50 | D – 9 |
| 4AA–22259–60 | D – 9 |
| 4AA–22259–80 | D – 9 |
| 1C3–22355–00 | D – 7 |
| 4EW–22474–00 | D – 9 |
| 3JE–22475–00 | D – 9 |
| 5NY–22475–00 | D – 9 |
| 1C3–22565–00 | D – 9 |
| 5UN–22898–60 | E – 8 |
| 1C3–22969–90 | D – 7 |
| 5XC–23102–G0 | D – 12 |
| 5XC–23102–H0 | D – 12 |
| 5XC–23103–G0 | D – 13 |
| 5XC–23103–H0 | D – 13 |
| 5XC–23110–M0 | D – 13 |
| 1C3–23111–L1 | D – 12 |
| 276–23114–00 | D – 12 |
| 5XC–23120–M0 | D – 12 |
| 5XE–23125–L0 | D – 12 |
| 1C3–23136–N0 | D – 12 |
| 1C3–23141–A1 | F – 2 |
| 1C3–23141–B1 | F – 2 |
| 1C3–23141–C1 | F – 2 |
| 1C3–23141–E1 | F – 2 |
| 1C3–23141–F1 | F – 2 |
| 1C3–23141–G1 | F – 2 |
| 1C3–23141–H1 | F – 2 |
| 1C3–23141–J1 | F – 2 |
| 1P8–23141–M1 | D – 12 |
| 1C3–23142–L0 | D – 12 |
| 5XE–23144–L0 | D – 12 |
| 1C3–23145–M0 | D – 12 |
| 5XE–23146–L0 | D – 12 |
| 1AE–23147–00 | D – 12 |
| 1C3–23147–L0 | D – 12 |
| 1C3–2314F–M0 | D – 12 |

| PART NO. | GRID NO. |
|---|---|
| 5XE–23153–L0 | D – 12 |
| 2HH–23158–L0 | D – 12 |
| 1C3–2315H–10 | D – 14 |
| 1C3–2315J–10 | D – 14 |
| 5XC–2316A–R0 | D – 12 |
| 5XC–2316A–S0 | D – 12 |
| 5XC–23170–M0 | D – 12 |
| 5XC–23170–N0 | D – 12 |
| 5XE–23171–L0 | D – 12 |
| 5DH–23183–00 | D – 9 |
| 509–23184–L0 | D – 9 |
| 1C3–23188–L0 | D – 12 |
| 1C3–23188–N0 | D – 12 |
| 1C3–23188–P0 | D – 12 |
| 1C3–23188–R0 | D – 12 |
| 1C3–23190–L0 | D – 12 |
| 5XC–23340–N0 | D – 14 |
| 3SP–23356–L0 | D – 14 |
| 5XE–23389–00 | D – 11 |
| 4EW–23416–00 | D – 11 |
| 2S2–23435–70 | D – 11 |
| 5XC–23441–90 | D – 11 |
| 2S2–23442–70 | D – 11 |
| 1C3–23466–50 | D – 14 |
| 1C3–23467–50 | D – 14 |
| 1C3–23485–80 | D – 11 |
| 2S2–24110–70 | D – 15 |
| 4EW–2412F–00 | D – 15 |
| 5XE–24144–00 | D – 15 |
| 3FB–2415E–01 | D – 3 |
| 3ME–2415E–01 | D – 4 |
| 3FB–2415E–11 | D – 3 |
| 3FB–2415E–C0 | D – 3 |
| 4SR–2416E–00 | D – 3 |
| 5XC–24181–90 | D – 15 |
| 5XC–24182–90 | E – 2 |
| 5XC–24183–90 | E – 2 |
| 3JD–24186–00 | D – 15 |
| 5UM–2419A–E0 | D – 15 |
| 5XC–24311–G0 | D – 15 |
| 5XC–24339–90 | D – 15 |
| 3XJ–24380–00 | D – 15 |
| 4JT–24500–10 | D – 15 |
| 4X8–24512–00 | D – 15 |
| 3AC–24523–00 | D – 15 |
| 3AJ–24534–01 | D – 15 |
| 5NY–24610–00 | D – 15 |
| 2S2–2470F–80 | E – 3 |

| PART NO. | GRID NO. |
|---|---|
| 5XC–2470F–90 | E – 3 |
| 5XC–2470F–A0 | E – 3 |
| 5XC–2470F–B0 | E – 3 |
| 2S2–24710–70 | E – 3 |
| 2S2–24710–80 | E – 3 |
| 5XC–24710–A0 | E – 3 |
| 5XC–24710–B0 | E – 3 |
| 5NY–25104–00 | E – 4 |
| 5NY–25111–00 | E – 4 |
| 5NY–25117–00 | E – 4 |
| 5XC–25181–G0 | E – 4 |
| 5XC–25183–G0 | E – 4 |
| 5XC–25186–G0 | E – 4 |
| 5HD–25304–00 | E – 6 |
| 5TJ–2530S–80 | E – 7 |
| 5ET–25311–00 | E – 6 |
| 5ET–25317–00 | E – 6 |
| 4XM–25364–00 | E – 6 |
| 1C3–25381–90 | E – 7 |
| 1C3–25388–50 | E – 7 |
| 1C3–25389–00 | E – 7 |
| 4XM–25394–00 | E – 6 |
| 5SF–25394–00 | E – 4 |
| 1C3–25447–00 | E – 6 |
| 1C3–25448–00 | E – 6 |
| 1C3–25449–00 | E – 6 |
| 1C3–25450–00 | E – 6 |
| 1C3–25451–00 | E – 6 |
| 1C3–25452–00 | E – 6 |
| 5CG–25715–00 | E – 10 |
| | E – 12 |
| 1C3–25718–50 | E – 8 |
| 5XC–2580T–G0 | E – 5 |
| 1C3–2580W–50 | E – 8 |
| 5XC–2581T–G0 | E – 5 |
| 5UN–25827–60 | E – 8 |
| 5UN–25828–60 | E – 8 |
| 2S2–2582W–70 | E – 8 |
| 5MV–25833–00 | E – 10 |
| 1C3–2583V–00 | E – 12 |
| 5XC–25849–G0 | E – 5 |
| 5UN–25852–50 | E – 12 |
| 5XC–25852–G0 | E – 10 |
| 5XC–25853–G0 | E – 10 |
| 5UN–25854–00 | E – 12 |
| 5XC–25854–G0 | E – 10 |
| 5UN–2585B–00 | E – 12 |
| 5MV–25867–00 | E – 10 |

| PART NO. | GRID NO. |
|---|---|
| 1C3–25872–90 | E – 10 |
| 1C3–25873–00 | E – 12 |
| 1C3–25876–50 | E – 12 |
| 1C3–25886–50 | E – 12 |
| 5MV–2589F–00 | E – 10 |
| 5UN–25914–00 | E – 8 |
| 5DH–25914–50 | E – 8 |
| 3SP–25914–51 | E – 5 |
| 5DH–25916–00 | E – 5 |
| | E – 8 |
| 3JD–25917–00 | E – 5 |
| | E – 8 |
| 5DH–25919–00 | E – 5 |
| 5DH–25919–50 | E – 8 |
| 8CR–25924–00 | E – 8 |
| 3SP–25926–51 | E – 5 |
| 5DH–25933–00 | E – 5 |
| 1UY–25937–51 | E – 5 |
| | E – 8 |
| 1C3–26111–90 | E – 9 |
| 5XC–26124–90 | E – 9 |
| 2S2–26143–70 | E – 9 |
| 5XC–26143–90 | E – 9 |
| 5TJ–26240–C0 | E – 9 |
| 4GY–26241–00 | E – 9 |
| 4GY–26242–00 | E – 9 |
| 3Y1–26249–00 | E – 9 |
| 5BE–26281–00 | E – 9 |
| 5BE–26282–00 | E – 9 |
| 5SF–26287–10 | E – 9 |
| 5XC–26302–G0 | E – 9 |
| 5XC–26334–G0 | E – 14 |
| 5XC–26335–G0 | E – 9 |
| 5HD–26337–00 | E – 14 |
| 5TA–26339–00 | E – 14 |
| 1C3–26342–50 | E – 9 |
| 5HD–26372–00 | E – 14 |
| 5XC–26372–G0 | E – 10 |
| 5UM–27200–00 | E – 11 |
| 5UN–27217–00 | E – 12 |
| 5XC–27217–90 | E – 11 |
| 5UN–27218–00 | E – 12 |
| 5UN–27222–00 | E – 12 |
| 1C3–27311–00 | E – 11 |
| 5XE–27411–01 | E – 11 |
| 5XE–27421–01 | E – 11 |
| 1C3–27491–50 | E – 8 |
| 5XC–28116–00 | D – 2 |

| PART NO. | GRID NO. |
|---|---|
| 5TA–2814F–00 | D – 2 |
| 5ET–28166–10 | D – 2 |
| 5UL–82310–10 | E – 15 |
| 5XC–82509–00 | E – 15 |
| 5XC–82540–00 | E – 15 |
| 5XE–82911–00 | E – 14 |
| 5XD–82913–00 | E – 14 |
| 5XD–82946–00 | E – 14 |
| 5MV–83912–00 | E – 14 |
| 5XC–83922–G0 | E – 10 |
| 5TA–83941–00 | E – 14 |
| 5HD–83951–00 | E – 14 |
| 1C3–83976–00 | E – 14 |
| 5LP–84126–10 | E – 14 |
| 5XC–85540–G0 | E – 15 |
| 1C3–85546–00 | E – 15 |
| 5TA–85550–00 | E – 13 |
| 5XC–85560–00 | E – 13 |
| 5XC–85885–00 | C – 3 |
| 5XC–W0041–00 | E – 10 |
| 5UN–W0042–50 | E – 12 |
| 5XC–W0045–00 | E – 5 |
| 1C3–W0046–50 | E – 8 |
| 5KM–W0047–10 | E – 5 |
| 5UN–W0047–50 | E – 8 |
| 1UY–W0048–50 | E – 5 |
| | E – 8 |
| 5XC–W0057–00 | E – 5 |
| 5UN–W0057–50 | E – 8 |
| 5XC–W2587–00 | E – 10 |
| 90101–06041 | C – 14 |
| 90101–06044 | C – 8 |
| 90101–08006 | E – 7 |
| 90105–05014 | D – 2 |
| 90105–06027 | B – 2 |
| 90105–06064 | D – 5 |
| 90105–06081 | C – 5 |
| | C – 12 |
| 90105–06094 | C – 7 |
| 90105–06098 | C – 6 |
| 90105–06100 | D – 3 |
| 90105–06103 | D – 5 |
| 90105–06104 | D – 7 |
| 90105–06105 | D – 7 |
| 90105–06106 | D – 3 |
| 90105–06107 | D – 11 |
| | D – 15 |
| | E – 8 |

| PART NO. | GRID NO. |
|---|---|
| 90105–06108 | E – 8 |
| 90105–06110 | E – 8 |
| 90105–06111 | B – 9 |
| | D – 15 |
| | E – 8 |
| 90105–06112 | D – 6 |
| 90105–06128 | D – 5 |
| 90105–08137 | C – 4 |
| | E – 5 |
| 90105–08143 | D – 2 |
| 90105–08146 | C – 15 |
| 90105–08147 | C – 15 |
| 90105–08150 | C – 15 |
| 90105–08151 | D – 5 |
| 90105–08154 | D – 11 |
| | D – 14 |
| 90105–08156 | C – 15 |
| 90105–08307 | C – 4 |
| | C – 15 |
| 90105–09002 | B – 2 |
| 90105–09004 | B – 2 |
| 90105–10174 | C – 15 |
| 90105–10176 | D – 2 |
| 90105–10191 | C – 15 |
| 90109–06034 | E – 14 |
| 90109–06193 | C – 13 |
| 90109–067F4 | B – 13 |
| 90109–08078 | E – 7 |
| 90110–05038 | B – 13 |
| 90110–06228 | B – 12 |
| 90110–08051 | C – 8 |
| 90111–06059 | E – 12 |
| 90116–06038 | B – 2 |
| 90119–06146 | D – 2 |
| 90119–06147 | D – 3 |
| 90119–06151 | D – 11 |
| 90119–08095 | D – 5 |
| 90122–06005 | B – 13 |
| 90149–05162 | E – 14 |
| 90149–06074 | C – 5 |
| 90149–06084 | B – 4 |
| 90149–06085 | C – 5 |
| 90149–06108 | E – 2 |
| 90149–06121 | E – 13 |
| 90149–06327 | E – 5 |
| 90149–10031 | C – 15 |
| 90151–04003 | D – 7 |
| 90151–06032 | D – 2 |

| PART NO. | GRID NO. |
|---|---|
| 90152–06010 | C – 8 |
| 90154–05022 | E – 15 |
| 90159–06092 | C – 9 |
| 90170–14171 | B – 4 |
| 90170–16326 | C – 9 |
| 90170–24003 | D – 11 |
| 90179–06028 | D – 7 |
| 90179–08674 | E – 7 |
| 90179–10658 | C – 15 |
| 90179–12657 | E – 13 |
| 90179–16011 | E – 4 |
| 90179–18001 | C – 9 |
| | C – 12 |
| 90179–28003 | D – 11 |
| 90183–060A6 | B – 9 |
| 90185–08008 | E – 7 |
| 90185–08009 | C – 15 |
| 90185–10012 | D – 10 |
| 90185–14010 | D – 8 |
| 90185–16002 | D – 7 |
| 90185–20002 | E – 7 |
| 90201–03313 | B – 13 |
| 90201–06032 | D – 3 |
| 90201–06570 | D – 15 |
| 90201–06571 | B – 9 |
| | D – 3 |
| | D – 6 |
| 90201–06630 | D – 5 |
| 90201–08043 | C – 15 |
| 90201–08044 | E – 11 |
| 90201–08045 | C – 15 |
| 90201–08048 | C – 8 |
| | E – 7 |
| 90201–08061 | C – 4 |
| 90201–080H1 | C – 9 |
| 90201–082A6 | D – 5 |
| 90201–08410 | C – 3 |
| 90201–08512 | B – 8 |
| 90201–096J9 | B – 2 |
| 90201–10032 | E – 11 |
| 90201–10045 | C – 15 |
| 90201–12166 | B – 10 |
| 90201–127E1 | E – 13 |
| 90201–14020 | D – 8 |
| 90201–15701 | C – 6 |
| 90201–16018 | D – 7 |
| 90201–162H4 | C – 8 |
| 90201–167P7 | C – 8 |

| PART NO. | GRID NO. |
|---|---|
| 90201–177G4 | C – 8 |
| 90201–20020 | E – 7 |
| 90201–20685 | C – 8 |
| 90201–21014 | D – 7 |
| 90201–24016 | D – 11 |
| 90201–286K9 | D – 11 |
| 90202–05193 | E – 2 |
| 90202–08045 | B – 14 |
| 90206–06090 | C – 4 |
| 90209–06014 | B – 13 |
| 90209–16011 | D – 7 |
| 90209–20008 | C – 11 |
| 90209–23012 | C – 11 |
| 90215–14204 | B – 4 |
| 90215–16289 | C – 9 |
| 90215–20003 | C – 9 |
| | C – 11 |
| 90240–08120 | E – 11 |
| 90240–10004 | E – 11 |
| 90267–32070 | B – 13 |
| 90267–48084 | C – 4 |
| | F – 3 |
| 90280–03006 | B – 4 |
| 90340–12007 | B – 2 |
| 90340–14128 | C – 6 |
| 90340–32123 | C – 6 |
| 90387–06009 | D – 3 |
| 90387–06065 | B – 9 |
| | D – 15 |
| 90387–06090 | D – 3 |
| | D – 15 |
| 90387–06104 | D – 11 |
| 90387–06150 | D – 6 |
| 90387–06161 | D – 6 |
| 90387–08041 | C – 15 |
| 90387–08081 | C – 4 |
| | F – 3 |
| 90387–086N4 | C – 15 |
| 90387–124F4 | C – 14 |
| 90387–14005 | D – 8 |
| 90387–16010 | D – 7 |
| 90387–18004 | D – 7 |
| 90387–18007 | C – 5 |
| 90387–18012 | D – 7 |
| 90387–20006 | C – 11 |
| 90387–22001 | C – 11 |
| 90387–225N2 | E – 9 |
| 90401–08006 | B – 12 |

| PART NO. | GRID NO. |
|---|---|
| 90401–10015 | B – 12 |
| 90401–10172 | E – 10 |
| | E – 12 |
| 90430–06014 | B – 2 |
| | B – 8 |
| 90430–08119 | B – 12 |
| 90430–10005 | E – 10 |
| | E – 12 |
| 90430–10188 | B – 12 |
| | C – 5 |
| 90445–09220 | D – 15 |
| 90445–09251 | D – 15 |
| 90445–14010 | B – 11 |
| 90450–17001 | B – 11 |
| 90450–22001 | B – 9 |
| | B – 10 |
| 90450–25001 | B – 9 |
| 90450–32003 | B – 9 |
| 90450–57010 | B – 13 |
| 90450–61002 | B – 13 |
| 90464–13073 | E – 15 |
| 90464–13077 | E – 15 |
| 90464–15195 | E – 15 |
| 90465–08029 | C – 7 |
| 90465–10013 | C – 5 |
| 90465–13275 | E – 2 |
| | E – 15 |
| 90467–090A2 | B – 9 |
| 90467–100A1 | E – 2 |
| 90467–140A4 | B – 2 |
| 90468–16001 | E – 11 |
| 90480–08608 | E – 7 |
| 90480–10289 | D – 5 |
| 90480–14433 | D – 6 |
| 90480–15528 | B – 9 |
| 90480–18549 | D – 15 |
| 90501–043E0 | B – 12 |
| 90501–052G5 | C – 14 |
| 90501–06022 | C – 13 |
| 90501–147A5 | C – 8 |
| 90501–160A2 | C – 8 |
| 90501–224J9 | C – 9 |
| 90506–16007 | E – 11 |
| 90508–26561 | C – 13 |
| 90508–28015 | E – 11 |
| 90508–28018 | E – 11 |
| 90508–291A8 | C – 14 |
| 90508–30743 | C – 8 |

| PART NO. | GRID NO. |
|---|---|
| 91312–06016 | D – 5 |
| 91312–06020 | B – 9 |
| 91312–06025 | B – 10 |
| | B – 12 |
| | B – 13 |
| 91312–06045 | C – 5 |
| 91312–06055 | C – 5 |
| 91312–06065 | B – 12 |
| 91312–06070 | C – 5 |
| 91316–04012 | B – 14 |
| 91317–06030 | B – 10 |
| 91402–20012 | E – 11 |
| 91402–25015 | E – 11 |
| 91808–16023 | B – 2 |
| 91812–16001 | C – 6 |
| 91A20–05065 | B – 9 |
| 92012–05008 | D – 2 |
| 92012–05012 | E – 14 |
| 92012–06010 | B – 9 |
| 92902–06600 | B – 7 |
| 92902–08200 | D – 2 |
| 92902–10200 | D – 10 |
| | D – 11 |
| 93101–14164 | C – 6 |
| 93102–12106 | B – 8 |
| 93102–12224 | C – 9 |
| | C – 14 |
| 93102–18278 | C – 8 |
| 93102–26468 | E – 4 |
| 93102–28010 | C – 11 |
| 93106–22002 | D – 7 |
| 93106–30001 | E – 6 |
| 93106–30045 | E – 6 |
| 93109–11073 | B – 8 |
| 93109–21001 | D – 8 |
| 93109–25001 | D – 7 |
| 93109–28043 | D – 7 |
| 93210–07003 | B – 12 |
| 93210–07135 | B – 12 |
| 93210–09008 | B – 12 |
| 93210–09754 | B – 11 |
| 93210–10197 | B – 10 |
| | C – 5 |
| 93210–11073 | E – 11 |
| 93210–12759 | B – 12 |
| 93210–14369 | C – 6 |
| | D – 5 |
| 93210–16275 | B – 9 |

# NUMERICAL INDEX


| PART NO. | GRID NO. |
|---|---|
| 93210–16716 | C – 6 |
| 93210–17570 | C – 8 |
| 93210–19123 | C – 6 |
| 93210–196A4 | C – 11 |
| 93210–21276 | E – 15 |
| 93210–32172 | C – 6 |
| 93210–47675 | B – 12 |
| 93300–60839 | C – 15 |
| 93306–00105 | B – 8 |
| 93306–00317 | C – 11 |
| 93306–00320 | C – 11 |
| 93306–07202 | E – 6 |
| 93306–20335 | B – 4 |
| 93306–20447 | C – 11 |
| 93306–20648 | B – 4 |
| 93306–27208 | C – 11 |
| 93306–27212 | E – 6 |
| 93306–90409 | E – 4 |
| 93306–90509 | C – 13 |
| 93310–63238 | B – 4 |
| 93311–32261 | B – 4 |
| 93315–32166 | D – 7 |
| 93317–11287 | C – 9 |
| 93317–22262 | D – 7 |
| 93332–00068 | D – 11 |
| 93332–00081 | D – 14 |
| 93340–21008 | C – 9 |
| 93342–22217 | D – 7 |
| 93410–20038 | C – 8 |
| 93410–22039 | C – 11 |
| 93410–26067 | C – 11 |
| 93420–16086 | B – 4 |
| 93440–07149 | B – 2 |
| 93440–07182 | B – 8 |
| | C – 9 |
| 93440–10153 | B – 2 |
| | B – 10 |
| 93440–41178 | B – 7 |
| 93503–08007 | B – 12 |
| 93507–32009 | C – 8 |
| 93511–32027 | C – 9 |
| 93603–16219 | B – 10 |
| 93604–10011 | B – 8 |
| 93608–33002 | C – 14 |
| 93612–16254 | B – 3 |
| | C – 5 |
| 9383B–13218 | C – 11 |
| 94108–21012 | E – 4 |
| 94108–21015 | E – 4 |
| 94108–2112Y | E – 4 |
| 94110–19009 | E – 6 |
| 94110–19012 | E – 6 |
| 94110–1913B | E – 6 |
| 94209–21229 | E – 4 |
| 94210–19222 | E – 6 |
| 94210–19224 | E – 6 |
| 94227–21101 | E – 4 |
| 94309–21161 | E – 4 |
| 94316–19156 | E – 6 |
| 94321–19135 | E – 6 |
| 94330–21084 | E – 4 |
| 94416–21034 | E – 4 |
| 94418–19008 | E – 6 |
| 94591–53114 | B – 7 |
| 94681–68001 | E – 7 |
| 94701–00410 | B – 2 |
| 94701–00411 | B – 2 |
| 94703–00410 | B – 2 |
| 94703–00411 | B – 2 |
| 95022–06010 | B – 2 |
| | C – 10 |
| 95022–06012 | B – 8 |
| | B – 12 |
| 95022–06016 | B – 10 |
| 95022–06020 | C – 14 |
| 95022–06025 | B – 7 |
| | B – 8 |
| | B – 10 |
| | C – 6 |
| 95022–06035 | B – 3 |
| | C – 6 |
| 95022–06065 | B – 8 |
| 95022–08040 | C – 15 |
| 95022–10016 | C – 5 |
| 95602–05100 | E – 14 |
| 95602–10200 | D – 10 |
| | D – 11 |
| 95612–08620 | B – 2 |
| 95701–06500 | E – 10 |
| 95702–06500 | B – 3 |
| | D – 14 |
| 95702–08500 | B – 2 |
| 97002–05016 | E – 14 |
| 97022–06016 | B – 7 |
| 97702–60016 | D – 3 |
| 98502–03008 | D – 15 |
| 98502–05010 | E – 12 |
| 98502–05020 | E – 9 |
| 98502–06025 | C – 5 |
| 98702–06025 | D – 15 |
| 98706–04012 | E – 10 |
| 98980–06008 | C – 4 |
| 99001–08600 | B – 10 |
| 99009–12400 | B – 10 |
| 99009–16400 | C – 8 |
| 99009–17400 | C – 8 |
| 99009–22500 | C – 6 |
| 99009–45500 | E – 6 |
| 99530–08012 | B – 10 |
| 99530–08016 | C – 6 |
| 99530–10114 | B – 10 |
| | C – 5 |
| 99530–10116 | C – 5 |
| 9Y581–92111 | E – 7 |